

LDW 492 DCI AUTOMOTIVE

WORKSHOP MANUAL



LDW 492 DCI

AUTOMOTIVE



PREFACE

- Every attempt has been made to present within this service manual, accurate and up to date technical information.
However, development on the **LOMBARDINI** series is continuous.
Therefore, the information within this manual is subject to change without notice and without obligation.

- The information contained within this service manual is the sole property of **LOMBARDINI**.
As such, no reproduction or replication in whole or part is allowed without the express written permission of **LOMBARDINI**.



Information presented within this manual assumes the following:

- 1 - The person or people performing service work on **LOMBARDINI** series engines is properly trained and equipped to safely and professionally perform the subject operation;
 - 2 - The person or people performing service work on **LOMBARDINI** series engines possesses adequate hand and **LOMBARDINI** special tools to safely and professionally perform the subject service operation;
 - 3 - The person or people performing service work on **LOMBARDINI** series engines has read the pertinent information regarding the subject service operations and fully understands the operation at hand.
- This manual was written by the manufacturer to provide technical and operating information to authorised **LOMBARDINI** after-sales service centres to carry out assembly, disassembly, overhauling, replacement and tuning operations.
 - As well as employing good operating techniques and observing the right timing for operations, operators must read the information very carefully and comply with it scrupulously.
 - Time spent reading this information will help to prevent health and safety risks and financial damage.
Written information is accompanied by illustrations in order to facilitate your understanding of every step of the operating phases.



REGISTRATION OF MODIFICATIONS TO THE DOCUMENT

Any modifications to this document must be registered by the drafting body, by completing the following table.

Drafting body	Document code	Model N°	Edition	Revision	Issue date	Review date	Endorsed
DICOM/ATLO 	ED0053029770	51292	1°	00	21.10.2013	21.10.2013	

1	GENERAL INFORMATION ON SAFETY	9-12
	WARRANTY CLAUSES	9
	SERVICE GENERAL NOTES	9
	GLOSSARY AND TERMINOLOGY	9
	WARNINGS AND NOTES	10
	SAFETY RULES	10
	GENERAL SAFETY DURING OPERATING PHASES	11
	ENVIRONMENTAL IMPACT	11
	ENGINE ON ROTATING STAND - SAFETY PRECAUTIONS	12
2	TECHNICAL INFORMATION	13-28
	GENERAL DESCRIPTION OF THE ENGINE	13
	PROBLEMS AND RELATED CAUSES	14-15
	DIMENSIONS	16
	TECHNICAL SPECIFICATIONS	16-17
	ENGINE AND MANUFACTURER IDENTIFICATION	18
	PERFORMANCE GRAPH	18
	LDW 492 DCI ENGINE MAINTENANCE (UNSCHEDULED)	19
	COOLANT	20
	FUEL SPECIFICATIONS	20
	LUBRICANTS	21
	FUEL SUPPLY CIRCUIT	22-24
	LUBRICATION CIRCUIT	25
	COOLING SYSTEM - OPERATING PRINCIPLE	26-28
3	ENGINE ELECTRICAL CONTROL	30-47
	ENGINE ELECTRONIC CONTROL SYSTEM	30
	WIRING DIAGRAM OF THE ELECTRICAL/ELECTRONIC SYSTEM	31
	ENGINE-VEHICLE DIALOGUE SYSTEM	36
	ENGINE WIRING DIAGRAM	34-35
	ENGINE WIRING HARNESS	36-37
	ACCESSORY WIRING DIAGRAM	38
	CONNECTORS REQUESTED FOR INTERFACING WITH LOMBARDINI WIRING HARNESS	39
	COMPONENTS OF ENGINE ELECTRONIC CONTROL SYSTEM	40-47
	E.C.U. (Electronic control unit)	40
	Control Unit Identification Plate	40
	Installation Requirements	40
	Common Rail	41
	Electronic Injectors	42
	IMA Management	42
	Water Temperature Sensor	43
	Oil Pressure Sensor	43
	Accelerator Potentiometer inside the Cabin (Pedal-Integrated)	44
	Accelerator Potentiometre as an Accessory (Remote-Controlled via Accelerator Cable)	44
	Glow Plugs	45
	Speed Sensor	45
	Electric Fan	46
	Starter Motor	46
	Alternator	47
	External Alternator Load Curve Graph	47
4	ENGINE STORAGE AND CONSERVATION	48-49
	HANDLING AND LIFTING	48
	ENGINE STORAGE	49
	PROTECTIVE TREATMENT	49
	PREPARING THE ENGINE FOR OPERATION AFTER PROTECTIVE TREATMENT	49

5 DISASSEMBLY..... 50-71

RECOMMENDATIONS FOR DISASSEMBLY	50
Alternator and Drive Belt	55
Alternator Drive Pulley	61
Balance Countershafts	71
Camshaft	66
Camshaft Cover	66
Connecting Rod Big End Caps	69
Coolant Outlet Flange and Thermostatic Valve	60
Crankcase	70
Crankshaft	71
Cylinder Head	67
Electronic Injectors	58
Engine Block	71
Engine Wiring Harness	50-52
Exhaust Manifold	53
Extracting the Electronic Injectors from the Cylinder Head	59
Flywheel	63
Fuel Distributor	57
Fuel Supply Hoses	55
Gear Cover	68
Glow Plugs	60
Head Gasket	68
High-Pressure Line between Injection Pump and Rail	58
High-Pressure Pump	65
Injection Pump Supply Hoses	56
Injector High-Pressure Hoses	56-57
Injector Return Line	56
Inlet Manifold	54
Intake System and Ducts	53-54
Oil Filter Cartridge	60
Oil Pump	69
Oil Pump Gear	68
Oil Sump	69
Overpressure Return Line	57
Piston	70
Rail	59
Rocker Arms and Hydraulic Tappets	67
Service Wiring Harness	52-53
Speed Sensor	64
Starter Motor	61
Starter Motor Support Plate	64
Tightening Pulley	63
Timing System	62
Water Pump	63
Water Temperature Sensor	60

6 OVERHAULING AND TUNING UP 72-91

RECOMMENDATIONS FOR OVERHAUL AND TUNING	72
OVERHAULING THE CRANK MECHANISM AND CRANKCASE	72
Balance Countershafts	77
Camshaft	89
Camshaft cover inspection	88
Connecting Rod - Check of Axis Parallelism	78
Connecting Rod - Overhauling and Dimensional Check	77-78
Crankshaft	76
Crankshaft - Axial Clearance Check	76
Cylinder Head and Components - Overhauling	83
Cylinders	74
Glow Plug Specifications and Injector Protrusion	85
Head Gasket - Determining the Thickness	79

High-Pressure Pump	90-91
Hydraulic Tappet	87
Oil Pressure Relief Valve	82
Oil Pump	81
Piston	73-74
Rings	75
Timing System	86
Timing System - Timing Angle Scheme	86
Valve Guides - Overhauling and Check	84
Valve Seats - Check	84
Valve Springs	83
Valves - Reassembly	85
Valves Guides and Housings	85
Vapour Recirculation Vent	80
Vapour Recirculation Vent - Operating Principle	80

7 REASSEMBLY..... 92-121

RECOMMENDATIONS FOR REASSEMBLY	92
Air Filter	118
Air Filter Duct - Vent Duct	117
Air Filter Support Bracket	117
Alternator	116
Alternator Drive Belt	116
Alternator Drive Pulley	107
Balance Countershafts	93
Camshaft	102
Camshaft Cover	102
Camshaft Seal Rings	103
Camshaft Toothed Pulley	105
Clearance Volume	100
Common Rail	111
Common Rail Fixing Columns - Tightening	112
Connecting Rod Cap	97-98
Coolant Inlet Flange	108
Coolant Outlet Flange	108
Crankcase - Fixing	95
Crankshaft	93
Crankshaft Seal Rings (Flywheel Side)	103
Crankshaft Seal Rings (Timing System Side)	104
Electronic Injector Fixing Bracket	109
Electronic Injectors	109
Electronic Injectors - Tightening	112
Engine Cylinder Head	101
Engine Wiring Harness - Installation	119-121
Exhaust Manifold	118
External Timing Belt Guard	107
Flywheel	100
Fuel Hoses	113
Gear Cover	104
Glow Plugs	109
High-Pressure Lines	111
High-Pressure Pump	110-111
Injector Fittings - Tightening	112
Injector Hose Fittings on Rail and Injection Pump Hose - Tightening	112
Injector Return Line	115
Inlet Manifold	117
Internal Timing Belt Guard	104
Lower Crankcase - Half-Bearings	94-95
Oil Filter	107
Oil Pump - Lobes	94
Oil Pump - Plate	96
Oil Suction Pipe	98
Oil Sump	98
Piston - Connecting Rod- Gudgeon pin - Assembly	97

Rail	113-114
Rocker Arm Cover	113
Rocker Arms and Hydraulic Tappets	101
Service Wiring Harness - Installation	118-119
Speed Sensor	99
Speed Sensor - Air gap	100
Starter Motor	115
Starter Motor Support Plate	99
Synchronous Timing Belt - Installation	106
Synchronous Timing Belt - Tensioning	106
Thermostatic Valve	108
Tightening Pulley	104
Timing Belt Setting	106
Timing System Drive Pulley	105
Upper Crankcase - Crankshaft Half-Bearings	92
Water Pump	103
Water Temperature Sensor	108
 8 TIGHTENING TORQUES AND USE OF SEALANT	 123-1225
Table with Tightening Torques for Standard Screws (Coarse Thread)	123
Table with Tightening Torques for Standard Screws (Fine Thread)	123
Table with Tightening Torques of the Main Components and Use of Sealant	124-135
 9 SPECIFIC TOOLS	 126
 10 DIAGNOSIS	 128-132

WARRANTY CERTIFICATE

- The products manufactured by Lombardini Srl are warranted to be free from conformity defects for a period of 24 months from the date of delivery to the first end user.
- For engines fitted to stationary equipment, working at constant load and at constant and/or slightly variable speed within the setting limits, the warranty covers a period up to a limit of 2000 working hours, if the above mentioned period (24 months) is not expired.
- If no hour-meter is fitted, 12 working hours per calendar day will be considered.
- For what concerns the parts subject to wear and deterioration (injection/feeding system, electrical system, cooling system, sealing parts, non-metallic pipes, belts) warranty covers a maximum limit of 2000 working hours, if the above mentioned period (24 months) is not expired.
- For correct maintenance and replacement of these parts, it is necessary to follow the instructions reported in the documentation supplied with each engine.
- To ensure the engine warranty is valid, the engine installation, considering the product technical features, must be carried out by qualified personnel only.
- The list of the Lombardini authorized dealers is reported in the "Service" booklet, supplied with each engine.
- Special applications involving considerable modifications to the cooling/lubricating system (for ex.: dry oil sump), filtering system, turbo-charged models, will require special written warranty agreements.
- Within the above stated periods Lombardini Srl directly or through its authorized network will repair and/or replace free of charge any own part or component that, upon examination by Lombardini or by an authorized Lombardini agent, is found to be defective in conformity, workmanship or materials.
- Any other responsibility/obligation for different expenses, damages and direct/indirect losses deriving from the engine use or from both the total or partial impossibility of use, is excluded.
- The repair or replacement of any component will not extend or renew the warranty period.

Lombardini warranty obligations here above described will be cancelled if:

- Lombardini engines are not correctly installed and as a consequence the correct functional parameters are not respected and altered.
 - Lombardini engines are not used according to the instructions reported in the "Use and Maintenance" booklet supplied with each engine.
 - Any seal affixed to the engine by Lombardini has been tampered with or removed.
 - Spare parts used are not original Lombardini.
 - Feeding and injection systems are damaged by unauthorized or poor quality fuel types.
 - Electrical system failure is due to components, connected to this system, which are not supplied or installed by Lombardini.
 - Engines have been disassembled, repaired or altered by any part other than an authorized Lombardini agent.
-
- Following expiration of the above stated warranty periods and working hours, Lombardini will have no further responsibility for warranty and will consider its here above mentioned obligations for warranty complete.
 - Any warranty request related to a non-conformity of the product must be addressed to the Lombardini Srl service agents.

GENERAL SERVICE MANUAL NOTES

- 1 - Use only genuine Lombardini repair parts.
Failure to use genuine Lombardini parts could result in sub-standard performance and low longevity.
- 2 - All data presented are in metric format. That is, dimensions are presented in millimeters (mm), torque is presented in Newton-meters (Nm), weight is presented in kilograms (Kg), volume is presented in liters or cubic centimeters (cc) and pressure is presented in barometric units (bar).

GLOSSARY AND TERMINOLOGY

For clarity, here are the definitions of a number of terms used recurrently in the manual.

- **Cylinder number one:** is the timing belt side piston.
- **Rotation direction:** anticlockwise «viewed from the flywheel side of the engine».

SAFETY AND WARNING DECALS

- Important remarks and features of the text are highlighted using symbols, which are explained below:



Danger – Attention

This indicates situations of grave danger which, if ignored, may seriously threaten the health and safety of individuals.



Caution – Warning

This indicates that it is necessary to take proper precautions to prevent any risk to the health and safety of individuals and avoid financial damage.



Important

This indicates particularly important technical information that should not be ignored.

SAFETY REGULATIONS

- **LOMBARDINI** Engines are built to supply their performances in a safe and long-lasting way.
To obtain these results, it is essential for users to comply with the servicing instructions given in the relative manual along with the safety recommendations listed below.
- The engine has been made according to a machine manufacturer's specifications and all actions required to meet the essential safety and health safeguarding requisites have been taken, as prescribed by the current laws in merit.
All uses of the engine beyond those specifically established cannot therefore be considered as conforming to the use defined by **LOMBARDINI** which thus declines all liability for any accidents deriving from such operations.
- The following indications are dedicated to the user of the machine in order to reduce or eliminate risks concerning engine operation in particular, along with the relative routine maintenance work.
- The user must read these instructions carefully and become familiar with the operations described.
Failure to do this could lead to serious danger for his personal safety and health and that of any persons who may be in the vicinity of the machine.
- The engine may only be used or assembled on a machine by technicians who are adequately trained about its operation and the deriving dangers.
This condition is also essential when it comes to routine and, above all, extraordinary maintenance operations which, in the latter case, must only be carried out by persons specifically trained by **LOMBARDINI** and who work in compliance with the existing documentation.
- Variations to the functional parameters of the engine, adjustments to the fuel flow rate and rotation speed, removal of seals, demounting and refitting of parts not described in the operation and maintenance manual by unauthorized personnel shall relieve **LOMBARDINI** from all and every liability for deriving accidents or for failure to comply with the laws in merit.
- On starting, make sure that the engine is as horizontal as possible, unless the machine specifications differ.
In the case of manual start-ups, make sure that the relative actions can take place without the risk of hitting walls or dangerous objects, also considering the movements made by the operator.
Pull-starting with a free cord (thus excluding self-winding starting only), is not permitted even in an emergency.
- Make sure that the machine is stable to prevent the risk of overturning.
- Become familiar with how to adjust the rotation speed and stop the engine.
- Never start the engine in a closed place or where there is insufficient ventilation.
Combustion creates carbon monoxide, an odourless and highly poisonous gas.
Lengthy stays in places where the engine freely exhausts this gas can lead to unconsciousness and death.
- The engine must not operate in places containing inflammable materials, in explosive atmospheres, where there is dust that can easily catch fire unless specific, adequate and clearly indicated precautions have been taken and have been certified for the machine.
- To prevent fire hazards, always keep the machine at least one meter from buildings or from other machinery.
- Children and animals must be kept at a due distance from operating machines in order to prevent hazards deriving from their operation.
- Fuel is inflammable.
The tank must only be filled when the engine is off.
Thoroughly dry any spilt fuel and move the fuel container away along with any rags soaked in fuel or oil.
Make sure that no soundproofing panels made of porous material are soaked in fuel or oil.
Make sure that the ground or floor on which the machine is standing has not soaked up any fuel or oil.
- Fully tighten the tank plug each time after refuelling.
Do not fill the tank right to the top but leave an adequate space for the fuel to expand.
- Fuel vapour is highly toxic.
Only refuel outdoors or in a well ventilated place.
- Do not smoke or use naked flames when refuelling.
- The engine must be started in compliance with the specific instructions in the operation manual of the engine and/or machine itself.
Do not use auxiliary starting aids that were not installed on the original machine (e.g. Startpilot').
- Before starting, remove any tools that were used to service the engine and/or machine.

- Make sure that all guards have been refitted.
- During operation, the surface of the engine can become dangerously hot.
Avoid touching the exhaust system in particular.
- Before proceeding with any operation on the engine, stop it and allow it to cool.
Never carry out any operation whilst the engine is running.
- The coolant fluid circuit is under pressure.
Never carry out any inspections until the engine has cooled and even in this case, only open the radiator plug or expansion chamber with the utmost caution, wearing protective garments and goggles. If there is an electric fan, do not approach the engine whilst it is still hot as the fan could also start operating when the engine is at a standstill.
Only clean the coolant system when the engine is at a standstill.
- When cleaning the oil-cooled air filter, make sure that the old oil is disposed of in the correct way in order to safeguard the environment.
The spongy filtering material in oil-cooled air filters must not be soaked in oil.
The reservoir of the separator pre-filter must not be filled with oil.
- The oil must be drained whilst the engine is hot (oil T ~ 80°C).
Particular care is required to prevent burns.
Do not allow the oil to come into contact with the skin.
- Pay attention to the temperature of the oil filter when the filter itself is replaced.
- Only check, top up and change the coolant fluid when the engine is off and cold.
Take care to prevent fluids containing nitrites from being mixed with others that do not contain these substances since "Nitrosamine", dangerous for the health, can form.
The coolant fluid is polluting and must therefore be disposed of in the correct way to safeguard the environment.
- During operations that involve access to moving parts of the engine and/or removal of rotating guards, disconnect and insulate the positive wire of the battery to prevent accidental short-circuits and to stop the starter motor from being energized.
- Only check belt tension when the engine is off.
- Only use the eyebolts installed by **LOMBARDINI** to move the engine.
These lifting points are not suitable for the entire machine; in this case, the eyebolts installed by the manufacturer should be used.

GENERAL SAFETY DURING OPERATING PHASES

- The procedures contained in this manual have been tested and selected by the manufacturer's technical experts, and hence are to be recognised as authorised operating methods.
- A number of procedures must be carried out with the aid of equipment and tools that simplify and improve the timing of operations.
- All tools must be in good working condition so that engine components are not damaged and that operations are carried out properly and safely.
It is important to wear the personal safety devices prescribed by work safety laws and also by the standards of this manual.
- Holes must be lined up methodically and with the aid of suitable equipment. Do not use your fingers to carry out this operation to avoid the risk of amputation.
- Some phases may require the assistance of more than one operator. If so, it is important to inform and train them regarding the type of activity they will be performing in order to prevent risks to the health and safety of all persons involved.
- Do not use flammable liquids (petrol, diesel, etc.) to degrease or wash components. Use special products.
- Use the oils and greases recommended by the manufacturer.
Do not mix different brands or combine oils with different characteristics.
- Discontinue use of the engine if any irregularities arise, particularly in the case of unusual vibrations.
- Do not tamper with any devices to alter the level of performance guaranteed by the manufacturer.

SAFETY AND ENVIRONMENTAL IMPACT

Every organisation has a duty to implement procedures to identify, assess and monitor the influence of its own activities (products, services, etc.) on the environment. Procedures for identifying the extent of the impact on the environment must consider the following factors:


- Liquid waste
- Waste management
- Soil contamination
- Atmospheric emissions
- Use of raw materials and natural resources
- Regulations and directives regarding environmental impact
- All packaging components must be disposed of in accordance with the laws of the country in which disposal is taking place.
- Keep the fuel and engine control systems and the exhaust pipes in efficient working order to limit environmental and noise pollution.
- When discontinuing use of the engine, select all components according to their chemical characteristics and dispose of them separately.

ENGINE ON ROTATING STAND - SAFETY PRECAUTIONS



Important


- Before removing the engine from the vehicle on which it is installed, disconnect the power supply, detach the fuel and coolant supply, and all connections including the mechanical ones.
- Attach the engine to a suitable lifting device (lifting beam).
- Hook the lifting device in the engine lifting points, as shown in the figure.
- Before lifting, make sure the weight is correctly balanced by checking its barycentre.
- Close all engine openings accurately (exhaust, intake, etc.), then wash the outside and dry with a jet of compressed air.
- Place the engine on a rotating stand to easily work on it.



Important

The bracket of the lifting points have been designed to lift the engine only. They are not intended nor approved to lift additional weights.


Do not use different methods to lift the engine than those described herein. In case different methods are used, no warranty shall be granted for any consequential damage.



Note: According to the intervention to be carried out, the engine may also be positioned on a workbench and secured using special support brackets (not supplied).

GENERAL DESCRIPTION OF THE ENGINE

Main Components



Description

- 4-stroke, 2 in-line cylinders Diesel engine.
- Aluminium alloy cylinder block and head.
- Timing system with two valves per cylinder, controlled by overhead camshaft driven by synchronous belt, roller rocker arms and hydraulic tappets.
- Electronically controlled direct injection (Common Rail).
- Forced lubrication by means of trochoid oil pump driven by left balance shaft.
- Double balance countershaft (total balancing of first order alternating forces).
- Forced circulation liquid-cooling system.

PROBLEMS AND RELATED CAUSES
THE ENGINE MUST BE STOPPED IMMEDIATELY WHEN:

- 1) - The engine rpms suddenly increase and decrease;
- 2) - A sudden and unusual noise is heard;
- 3) - The colour of the exhaust gas suddenly darkens;
- 4) - The oil pressure indicator light turns on while running;
- 5) - The coolant temperature indicator light turns on while running;
- 6) - The engine malfunction indicator light comes on.


TABLE OF ANOMALIES ACCORDING TO THEIR SYMPTOMS

The following table suggests the probable causes of some anomalies that may appear during engine operation. Always proceed systematically. Start from the basic checks before disassembling the engine or replacing its components.

POSSIBLE CAUSE		TROUBLE														
		Engine does not start	Engine starts but stops	No acceleration	Non-uniform speed	Black smoke	White smoke	Oil pressure too low	Oil level increase	Excessive oil consumption	Oil and fuel dripping from the exhaust	Engine overheats	Inadequate performance	High noise level	The Warning Lamp is ignited	
FUEL CIRCUIT	Clogged fuel hoses															
	Clogged fuel filter															
	Air or water in the fuel supply circuit															
	Clogged tank cap breather															
	Faulty fuel pump															
	Lack of fuel															
ELECTRIC SYSTEM	Glow plug fuse burnt-out															
	Flat battery															
	Inefficient or wrong cable connection															
	Faulty starter switch															
	Faulty starter motor															
	Faulty glow plugs															
	Speed sensor defective															
MAINTENANCE	Clogged air filter															
	Excessive idle operation															
	Incomplete running-in															
SETTINGS REPAIRS	Worn out or stuck rings															
	Worn out cylinders															
	Worn out valve guides															
	Bad valve seal															
	Crankshaft/Connecting rod bearings worn out															
	Cylinder head gasket damaged															
	Faulty valve timing															

POSSIBLE CAUSE		TROUBLE													
		Engine does not start	Engine starts but stops	No acceleration	Non-uniform speed	Black smoke	White smoke	Oil pressure too low	Oil level increase	Excessive oil consumption	Oil and fuel dripping from the exhaust	Engine overheats	Inadequate performance	High noise level	The Warning Lamp is ignited
LUBRICATION CIRCUIT	Excessive oil level														
	Low oil level														
	Dirty or blocked pressure regulating valve														
	Worn oil pump														
	Air in the oil suction pipe														
	Oil sump suction pipe clogged														
	Oil sump drainage pipe clogged														
INJECTION	Damaged injector														
	Damaged high-pressure pump														
	Wrong injector IMA codes														
COOLING CIRCUIT	Insufficient coolant														
	Defective fan, radiator, or radiator cap														
	Defective thermostatic valve														
	Coolant leaks from the radiator, ducts, crankcase or water pump.														
	Inside of radiator or coolant lines clogged														
	Defective or worn water pump														
	Heat exchange surface of the radiator clogged														

OVERALL DIMENSIONS



DIMENSIONS (mm)

A	318	D	189,1	G	525,7	M	220,5
B	157,2	E	475,1	H	350,6	N	500
C	98	F	212,5	L	175,1	P	314,8

GENERAL INFORMATION


Operating cycle	Four strokes Diesel	
Cylinders	n.	2 in-line
Bore x stroke	mm	69x64
Displacement	cm ³	478
Compression rate	20:1	
Suction	Dry-type air filter	
Cooling	Liquid	
Crankshaft rotation	Anticlockwise (seen from flywheel side)	
Combustion sequence	Crankshaft degrees	360°
Timing System	Single shaft driven by synchronous toothed belt	
Valves	n.	2 for cylinder
Shaft	overhead camshaft	
Tappets	hydraulic	
Injection	electronically-controlled direct injection (Common Rail)	
Engine dry weight	Kg	48.5
Maximum tilt during operation	less than 1 minute	25°
Maximum tilt during operation	less than 30 minutes	15°
Volume of sucked air (4000 rpm)	l/min	960
Minimum volume of radiator cooling air (at static pressure of 0 mm H2O)	m ³ /h	880
POWER AND TORQUE		
Peak rpm	giri/min.	4000
Peak power (NB 80/1269/EEC - ISO 1585 - DIN 7020)	kW	8,5
Maximum torque (N power at 2,000 rpm)	Nm	21
Admissible axial load on crankshaft	Kg	80

CONSUMPTIONS AT MAXIMUM POWER		
Specific fuel consumption	g/kWh	320
Oil consumption	g/h	0,0035
FUEL SUPPLY CIRCUIT		
Fuel type	Automotive Diesel fuel	
Fuel supply	Electric pump	
Fuel filter	cartridge	
Filtering surface	cm ²	2'400
Filtering capacity	µm	2 ÷ 3
Maximum circuit pressure	bar	0.5
LUBRICATION CIRCUIT		
Lubrication type	Totally forced	
Circuit supply	Trochoid pump	
Oil maximum quantity	filter included (l)	2,1
Oil maximum quantity	filter excluded (l)	2
Oil pressure switch		
Switching pressure (minimum value)	bar	0,3
Oil filter	External, full flow	
Maximum operating pressure	bar	6
Maximum bursting pressure	bar	20
Filtering capacity	µm	15
By-pass valve calibration	bar	1,3 ÷ 1,9
Filtering surface	cm ²	580
COOLING CIRCUIT		
Coolant	50% decalcified water - 50% anti-freeze liquid	
Water pump	on engine block, driven by timing belt	
Thermostatic valve		
Opening temperature	°C	78°÷82°
Stroke at 94°C	mm	7
Liquid recirculation (from Δp 0,5 bar)	l/h	30÷80
ELECTRICAL INSTALLATION - ELECTRIC FAN		
Rated voltage	V	12
Alternator (rated voltage)	V	14
External alternator (rated current)	A	45
Starter motor power	kW	1,1
System electrical consumption, excepted: glow plugs, electric pump, electric fan, starter motor	W	0,35
Coolant temperature indicator light sensor		
Electrical circuit	Unipolar system	
Supply voltage	V	6÷24
Absorbed power	W	3
Indicator light operating temperature	°C	106°÷108°

Battery not supplied by Lombardini

Recommended battery: **12 V 44 Ah / 400 A DIN**
 12 V 44 AH / 790 A EN


ENGINE AND MANUFACTURER IDENTIFICATION



The identification plate shown is applied directly on the engine. It shows the following information:

- A) Manufacturer identification
- B) Engine type
- C) Engine serial number
- D) Peak rpm
- E) Customer version number (K no.)
- F) Approval data

PERFORMANCE GRAPH



Legend

N* (80/1269/EEC-ISO 1585) = Power curve.

Automotive power: discontinuous services at variable RPM and load.

MN* = Torque curve

C* = specific consumption curve

* The above curves are approximate since they depend on applications and on engine mapping.

- In applications for quadricycles lightweight, the motor is calibrated at 4kW of law.
- The above power levels refer to the engine equipped with air filter, muffler, fully broken-in suction fan, and ambient conditions of 20°C and 1 bar.

- The maximum power is guaranteed with a tolerance of 5%.

- These power rates are reduced by approx. 1% every 100m of altitude and by 2% for every 5°C exceeding 25°C.

Note: Please contact Lombardini for power, torque, and specific consumption curves at different speeds from the above.



Caution – Warning

Non-approval by Lombardini for any modifications releases the company from any damages incurred by the engine.

LDW 442 CRS ENGINE MAINTENANCE

Important

Non compliance with the operations described in the table involves the risk of technical damages to the engine and vehicle. Any non compliance makes the warranty become null and void.

LDW 492 DCI ENGINE SCHEDULED MAINTENANCE

		PERIODICITY IN KM (PER 1,000 KM)													
		10	20	30	40	50	60	70	80	90	100				
OPERATION DESCRIPTION															
CLEANING AND CHECKING	Radiator fins														
	Engine oil level	EVERY 2,500 km													
	Oil vapour recirculation system														
	Fuel hoses and fittings														
	Coolant level	EVERY 2,500 km													
	Alternator belt tension														
	Air filter element														
CHANGE	Engine oil														
	Oil filter														
	Fuel filter														
	Air filter cartridge (**)														
	Coolant														
	Alternator belt														
	Timing belt (*)														
	Tightening pulley														
	Fuel hoses and safety filter														


Important

Even if the prescribed km have not been covered, the following items must be changed or replaced:

- engine oil, after one year
- coolant, after two years
- alternator belt, after four years
- timing belt, after four years

After 100,000 km, continue with the same maintenance intervals.

(*) Once removed, the timing belt must be replaced, even if it has not reached its prescribed service life.

(**) The period of time that must elapse before cleaning or replacing the filter element depends on the environment in which the engine operates. The air filter must be cleaned and replaced more frequently under very dusty conditions.

COOLANT

An anti-freeze protection liquid (eg. AGIP ANTIFREEZE SPEZIAL) – mixed with 50% decalcified water – must be used. As well as lowering the freezing point, the permanent liquid also raises the boiling point and protects the whole circuit from corrosion.

FUEL RECOMMENDATIONS

Purchase diesel fuel in small quantities and store in clean, approved containers. Clean fuel prevents the diesel fuel injectors and pumps from clogging. Do not overfill the fuel tank.

Leave room for the fuel to expand. Immediately clean up any spillage during refueling.

Never store diesel fuel in galvanized containers; diesel fuel and the galvanized coating react chemically to each other, producing flaking that quickly clogs filters or causes fuel pump or injector failure.

High sulfur content in fuel may cause engine wear. In those countries where diesel has a high sulfur content, it is advisable to lubricate the engine with a high alkaline oil or alternatively to replace the lubricating oil recommended by the manufacturer more frequently. The regions in which diesel normally has a low sulfur content are Europe, North America, and Australia.

PRESCRIBED LUBRICANT	
Fuel with low sulphur content	API CF4 - CG4
Fuel with high sulphur content	API CF

FUEL TYPE

For best results, use only clean, fresh, commercial-grade diesel fuel. Diesel fuels that satisfy the following specifications are suitable for use in this engine: ASTM D-975 - 1D or 2D, EN590, or equivalent.

FUELS FOR LOW TEMPERATURES

It is possible to run the engine at temperatures below 0°C using special winter fuels. These fuels reduce the formation of paraffin in diesel at low temperatures. If paraffin forms in the diesel, the fuel filter becomes blocked interrupting the flow of fuel.

Fuel can be:

- Summer up to 0°C
- Winter up to -10°C
- Alpine up to -20°C
- Arctic up to -30°C

BIODIESEL FUEL

Fuels containing less than 20% methyl ester or B20, are suitable for use in this engine. Biodiesel fuels meeting the specification of BQ-9000, EN 14214 or equivalent are recommended. DO NOT use vegetable oil as a biofuel for this engine. Any failures resulting from the use of fuels other than recommended will not be warranted.

AVIATION FUEL

Aviation fuels suitable for use in this engine include JP5, JP4, JP8 and, JET-A (if 5 percent oil is added).

EMISSION CONTROL INFORMATION

**LOW SULFUR FUEL OR
ULTRA LOW SULFUR FUEL ONLY**

**EPA /CARB emission label must be
attached near the fuel inlet.**

LUBRICANTS

Recommended oil

Description	Oil type	Oil characteristics
Engine oil	eni i-Sint 5W40	API SM-CF ACEA A3 - B4

Engine oil capacity

Oil volume at max. level (including oil filter)	Litres	2,1
Oil volume at max. level (without filter)	Litres	2,0

SAE classification


In the SAE classification oils are identified according to viscosity without considering any other qualitative characteristic.

The first number refers to the viscosity when cold, for use during winter (W= winter), while the second number is for viscosity at high temperatures.

The criteria for choosing an oil must include the minimum ambient temperature to which the engine is to be exposed during the winter and the maximum temperature during operation in the summer.

Monograde oils are generally used when the operating temperature varies little.

Multigrade oils are less sensitive to temperature variations.



International specifications

They define testing performances and procedures that the lubricants need to successfully respond to in several engine testing and laboratory analysis so as to be considered qualified and in conformity to the regulations set for each lubrication kind.

A.P.I. : (American Petroleum Institute)

MIL : Engine oil U.S. military specifications released for logistic reasons

ACEA : European Automobile Manufacturers Association

Tables shown on this page are of useful reference when buying a kind of oil.

Codes are usually printed-out on the oil container and the understanding of their meaning is useful for comparing different brands and choosing the kind with the right characteristics.

Usually a specification showing a following letter or number is preferable to one with a preceding letter or number.

An SF oil, for instance, is more performing than a SE oil but less performing than a SG one.


ACEA REGULATIONS - SEQUENCES

LIGHT DUTY DIESEL ENGINES		HEAVY DUTY DIESEL ENGINES	
B1 =	Low-viscosity, for frictions reduction	E2 =	Standard
B2 =	Standard	E3 =	Heavy conditions (Euro 1 - Euro 2 engines)
B3 =	High performances (indirect injection)	E4 =	Heavy conditions (Euro 1 - Euro 2 - Euro 3 engines)
B4 =	High quality (direct injection)	E5 =	High performances in heavy conditions (Euro 1 - Euro 2 - Euro 3 engines)


API / MIL SEQUENCES

API	CH-4	CG-4	CF-4	CF-2	CF	CE	CD	CC
MIL			L-46152 D / E					

FUEL SUPPLY CIRCUIT



Rif.	Description
1	Tank (not supplied)
2	Electric fuel pump
3	Fuel filter
4	Safety in-line filter
5	Common Rail
6	High-pressure pump
7	Electronic injectors
8	Return pressure regulating valve
9	Distributor
10	Pressure sensor
11	Pressure regulator




FUEL FILTER

A fuel filter is supplied with the engine, to be mounted on the vehicle frame.


Components

1. Air bleeding plug
2. Water in fuel sensor
3. Cartridge

Description	Value
Filtering surface	2.400 cm ²
Filtering capacity	2 µm
Max operating pressure	2.0 Bar
Max delivery	190 litres/hour



WATER IN FUEL SENSOR - WIRING DIAGRAM





FUEL DISTRIBUTOR

Key to components:

1. Injector 2 return line
2. Injector 1 return line
3. Pump return line (quick-coupling 5/16)
4. Non-return valve for injector return line
5. Rail return line
6. Return line outlet to tank
7. Inlet from fuel filter
8. Safety fuel filter
9. Delivery to high-pressure pump (quick-coupling 3/8)


ELECTRIC PUMP




Features

Voltage	12 V
Max absorbed current	1,5 A
Min pump delivery	30 L/h
Self-adjusting pressure	0,30 Bar
Operating pressure	0,10 Bar
Working temperature	-30/+60 °C.

Connector: AMP 282104/1




INJECTION PUMP



Description	Value
Pumping element	Ø 5.5 mm
Total stroke	5.7 mm
Working stroke	3.5 mm
Pre-stroke	2.2 mm


LUBRICATION CIRCUIT



Rif.	Description
1	Pressure switch
2	Oil sump suction
3	Oil filter cartridge
4	Oil pump
5	Oil pressure regulating valve
6	Oil drain plug
7	Oil return line
8	Oil dipstick
9	Vent system
10	Oil filler cap

In the sections in red the oil is under pressure, in the sections in blue the oil is in the return phase, i.e. not under pressure.

The oil pump is driven by the left balance shaft, seen from timing system side.



OIL PUMP

The oil pump is a trochoid-type lobe pump, and it is driven by the left balance shaft. The pump casing is partly integrated in the upper crankcase and partly in the lower one. The internal lobe is keyed onto the left balance shaft.

It is compulsory to assemble the external lobe with its reference turned outside, so that it is visible to the operator, as shown in the figure.


Features:

Pump type: lobe pump

Pump drive:

gear driven by crankshaft and installed on left balance shaft

Pressure regulating valve: installed on crankcase

COOLING SYSTEM OPERATING PRINCIPLE

Rif.	Description
1	Cab heating
2	Thermostatic valve
3	Liquid circulating pump suction
4	Liquid circulating pump
5	Liquid outlet from engine
6	Water temperature sensor






WATER PUMP

Features:

Delivery	75 l/min
Rpm	4,400
Gear ratio (Rmpump/Rpmengine)	0.96
Number of pump revolutions	4,224
Max working time.....	130°C


Water delivery graph (l/min)



THERMOSTATIC VALVE

Features:

Temperature for opening start:	80°C
Temperature for opening end:	95°C
Lift:	7 mm
Water recirculation:	30÷80 l/h

INTAKE SYSTEM**AIR FILTER**

The air filter is a dry-type one, with a replaceable paper filter cartridge.

The filter intake must be positioned in a cool area.


The temperature of the air sucked must never exceed ambient temperature by more than 10°C (if you are using a pipe, check that pipe length is 400 mm max and that it is the straightest possible).

Components:


1. Filter body
2. Filtering cartridge
3. Cover
4. Dust exhaust valve
5. Articulated fastener

[illegible]

ENGINE ELECTRONIC CONTROL SYSTEM



WIRING DIAGRAM OF THE ELECTRICAL/ELECTRONIC SYSTEM




The dotted parts are not supplied by Lombardini.

ENGINE-VEHICLE DIALOGUE SYSTEM

Key 50
Odometer control
Revolution indicator control
Control for alternator indicator light
Control for oil low pressure indicator light
Control for glow plug indicator light
Control for injection failure indicator light
Control for coolant high temperature indicator light
Control for water in fuel indicator light
6-gangs accelerator pedal
Brake pedal (STOP)
Signal for gearbox in neutral position
Signal handbrake

INSTRUMENT PANEL SCHEME




Speedometer-Odometer signal characteristics:

- 12-teeth phonic wheel on wheel axis
- Hall-effect sensor, 12 V power-supplied
- Squared waveform with 12 peaks 12 V per phonic wheel revolution (with Lombardini gearbox)

Revolution indicator specifications:

- Squared waveform with 2 peaks 12 V per engine revolution

Engine wiring diagram



1 - ACCESSORIES

LEGEND

V	Heater fan
E	Auxiliary Equipments Connector

2 - COCKPIT

LEGEND

N	Neutral lamp
W	Warnig lamp
T H ₂ O	Water temperature lamp
H	Glow plug lamp
S H ₂ O	Water in fuel lamp
A	Alternator lamp
P oil	Oil pressure lamp
B	Stop light (1kΩ / 2,25 W)
rpm	rpm
Km	Km
30	+ Battery
50	Cranking
15-54	Key on
D	Accelerator pedal connector
F	CAN connector
C	Connector for cockpit wiring
E	HAAnd brake lamp

3 - FUSE AND RELAIS

LEGEND

F1	Electric fan fuse - 15A
F2	AC pump fuse - 10A
F3	Fuse diagnostics and ECU - 10A
F4	Fuse - 15A
F6	Fuse - 10A
F9	Glow plug fuse - 25A
F10	Glow plug fuse - 25A
R1	Electric fan relay 30A
R4	Relay general 30A
RC	Relay plugs 70A

FUSE WIRING CONNECTORS

LEGEND

B	ECU Connector
C	Cockpit Connector
E	Auxiliary Equipments Connector
M	OBD Connector
S	Utilities Connector

CABLE COLOR

LEGEND

A	ORANGE
B	WHITE
BL	BLEU
C	LIGHT BLEU
G	YELLOW
GR	GREY
M	BROWN
N	BLACK
R	RED
RA	PINK
V	GREEN
VI	PURPLE

4 - SERVICES


LEGEND

CN1	Glow plug n° 1
CN2	Glow plug n° 2
G	Speed sensor (connected to gearbox)
MOT	Starter
S	Utilities Connector


5 - ENGINE WIRING HARNESS

LEGEND

L	Engine Speed
T	Rail Pressure Regulator
H	Oil Pressure Switch
N	Cyl Nr. °1 Injector
O	Cyl Nr. °2 Injector
ALT	Alternator
P	Water temp. sensor
Q	Timing sensor
R	Rail pressure sensor
A	Connector for engine wiring

ENGINE WIRING HARNESS

A - CONNETTORE ECU A		
	Posizione	Colore cavo
	A1	Grigio - Rosso
	A2	Grigio - Blu
	A3	V - G
	A4	-
	B1	Giallo
	B2	Verde
	B3	C
	B4	CN
	C1	CG
	C2	-
	C3	-
	C4	VR
	D1	-
	D2	-
	D3	-
	D4	VN
	E1	-
	E2	-
	E3	-
	E4	-
	F1	R - N
	F2	B - A
	F3	B - BL
	F4	-
	G1	M
	G2	V
	G3	BL - N
	G4	G
	H1	B
	H2	BL
	H3	-
	H4	-



LEGEND	
COLOUR	
A	ORANGE
B	WHITE
BL	BLEU
C	LIGHT BLEU
G	YELLOW
GR	GREY
M	BROWN
N	BLACK
R	RED
RA	PINK
V	GREEN

R - SENSORE DI PRESSIONE RAIL	
	Colore cavo 1 C - N
	Colore cavo 2 C
	Colore cavo 3 C - G

T - REGOLATORE DI PRESSIONE RAIL	
	Colore cavo 1 B - R
	Colore cavo 2 R

L - SENSORE DI GIRI	
	Colore cavo 1 G - BL
	Colore cavo 2 G - R

O - CONNETTORE ELETTROINIEETTORE	
	Colore cavo 1 BL
	Colore cavo 2 B


N - CONNETTORE ELETTROINIEETTORE	
	Colore cavo 1 G
	Colore cavo 2 BL - N

P - TEMP. LIQUIDO RAFFREDDAMENTO	
	Colore cavo 1 G
	Colore cavo 2 BL - N

ALT - ALTERNATORE	
	Colore cavo 1 B - BL
	Colore cavo 2 R - N


H - SENSORE PRESSIONE OLIO	
	Colore cavo 1 B - A


ACCESSORY WIRING DIAGRAM



CN1 - GLOW PLUG N° 1	
Cable colour	R

CN2 - GLOW PLUG N° 2	
Cable colour	R

MOT-50 THE STARTER MOTOR	
	Cable colour 1 B - R

S - CONNECTOR SERVICES	
	Cable colour 1 B - R
	Cable colour 2 R
	Cable colour 3 R

LEGEND	
A	COLOUR
A	ORANGE
B	WHITE
BL	BLEU
C	LIGHT BLEU
G	YELLOW
GR	GREY
M	BROWN
N	BLACK
R	RED
RA	PINK
V	GREEN

CONNECTORS REQUESTED FOR INTERFACING WITH LOMBARDINI WIRING HARNESS


<i>Description</i>	<i>Rif.</i>	<i>Manufacturer</i>	<i>Reference Code</i>
Cabin interface connection	C	FRAMATOME CONNECTORS	HCCMHPE24BKAFSV
Accelerator pedal connection		DELPHI	15326829
Accessory interface connection	E	TYCO	Connector: 174657-2 Terminals: 174658-7
Power supply connection	Z	MTA Spa	45.40300
Water in fuel filter sensor connection		TYCO	Connector: 282191-1

- Battery not supplied by Lombardini
- Recommended battery: 12 V 44 Ah / 400 A
12 V 44 Ah / 790 A EN


Important

- Never disconnect the battery cables immediately after engine stop.

COMPONENTS OF THE ENGINE ELECTRONIC CONTROL SYSTEM



ECU (Electronic control unit)

Control unit for engine and vehicle management.



Important


The control unit must be used only with the calibration defined by Lombardini s.r.l. for every single engine.



Control unit identification plate (Example)


1. Engine type
2. Approval code
3. Customer version number (K no.)
4. Engine s/n bar code
5. Engine s/n

- The control units are not interchangeable nor modifiable.
- Each control unit is accompanied by its adhesive identification plate.



Installation prescriptions

- Protection degree: 1P 6K/9K.
- Max continuous duty temperature: 115°C.
- Storing temperature: 125°C.
- Do not install the control unit on the engine. Always install it on the vehicle frame, in a cool area protected against shocks and humidity.
- When choosing the position of the control unit in an application, check that the air valve is protected against jets of battery liquid or direct water jets during engine washing.
- To avoid infiltrations in the wiring harness, make sure the connection area (ECU connector) is not the lowest point of the wiring harness.



COMMON RAIL


Components:

1. Pressure sensor
2. Pressure regulator
3. Common rail
4. High-pressure pump
5. Pressure regulator return line

The fuel is put under pressure by the high-pressure pump, driven by the roller tappet in contact with the camshaft.

The cam driving the pump has a double lift that provides a delivery for every injection.

The quantity of fuel put under pressure by the pump always exceeds the real needs of fuel.



1 - Pressure sensor

It sends a feedback signal to the injection control unit to adjust the injection pressure and duration.

When reassembling, tighten to a torque of 140 Nm.

2 - Pressure regulator


According to the signals sent by the engine control unit, it adjusts the pressure inside the rail by means of a ball valve that discharges the fuel in the low pressure line connected to the tank.

The regulator has an internal solenoid controlled by the engine control unit.

When the duty cycle is at 0%, the solenoid is not powered and the rail has a minimum pressure which is due to the pre-load of the ball valve spring.

3 - Rail

Its internal volume has been enhanced to obtain the best compromise possible between: (1) the need of minimizing the pressure peaks resulting from the cyclicity of the high-pressure pump delivery and the opening of the electronic injectors on the one hand, and (2) the improved response speed of the system to the requests of the engine control unit on the other hand.



ELECTRONIC INJECTORS

The electronic injectors are assembled on the cylinder head and are controlled by the injection control unit.

Electronic injector operating conditions

Operating pressure	250 ÷ 800 Bar
Return circuit pressure	0,3 ÷ 0,4 Bar
Blow-by pressure	1700 ÷ 1800 Bar
Fuel temperature	-30 ÷ 115° C
Over-pressure temperature (return)	max 125° C
External temperature	-30 ÷ 120° C
No. of holes and diameter	5 x 0,123 mm

IMA Management

During the test phase, the characteristics of the injectors are tested under different conditions of pressure/delivery.


Any injector that does not comply with a specific standard is discarded. The approved injectors are classified using a 9-digits alphanumeric code (IMA code), marked by means of laser-writing on the upper part of the electromagnet (**pos. A**).

This procedure allows combining the manufacturing characteristics of each injector with a specific software strategy of the engine control unit, thus improving the injector performances and reducing the polluting emissions.

The IMA procedure allows recovering the manufacturing tolerances of each injector tested.

Any time one or more injectors (or the ECU itself) are replaced, the new codes have to be stored in the memory to implement the corrections.

When installing the control unit, the single code has to be stored. In case of replacement of one or more injectors, the diagnostic tool must be used to enter the code of the new injector (see IMA code storing on page 130).



Main components of the electronic injector

A IMA code


1. Pressure rod
2. Needle
3. Nozzle
4. Coil
5. Pilot valve
6. Ball valve
7. Control area
8. Supply volume
9. Control volume
10. Fuel return (low pressure)
11. Control line
12. Supply line
13. Electrical connection
14. High-pressure fuel inlet union
15. Spring

Injector cleaning for new use

Immerse the injector, by keeping it in upright position, in an ultrasonic bath. Immerse it up to below the high-pressure union.

If necessary, clean the injector body and the nozzle sealing surface using a fine emery cloth to remove any residues left.

It is absolutely forbidden to remove the covers to clean the injector. No manual and/or mechanical cleaning of the nozzle is allowed.



WATER TEMPERATURE SENSOR


Water temperature sensor of the cooling circuit, fixed to the thermostat case.

It is used by the ECU to manage the signal for the high-temperature indicator light and to control the electric fan of the coolant radiator.

Indicator light switch-on temperature 106°C - 108°C.

- Tighten the water temperature sensor to a torque of 20 Nm.

CHARACTERISTICS		
Temp ° C	Rm in K Ω	Rm ax K Ω
-40	38.313	52.926
0	5.227	6.623
+140	0.067	0.076




OIL PRESSURE SENSOR


Assembled on the cylinder head at the end of the lubrication circuit.

It is a NC sensor, set to 0.3 bar ± 0.15.


It directly controls the indicator light on the vehicle instrument panel by closing the circuit to ground when the oil pressure is low.

ACCELERATOR POTENTIOMETER INSIDE THE CABIN (PEDAL-INTEGRATED)

KEY TO COMPONENTS

- | | |
|---------------------------|---------------------------------|
| 2. Pivot | 5. Small spring |
| 3. Complete potentiometer | 6. Pedal linking |
| 4. Big spring | 7. Pedal travel limiting device |

ACCELERATOR POTENTIOMETER AS AN ACCESSORY (REMOTE CONTROL WITH ACCELERATOR CABLE)

KEY TO COMPONENTS

- | | |
|----------------------------------|------------------------------------|
| 1. Accelerator cable | 5. Limit stop for idling position |
| 2. Potentiometer control lever | 6. Limit stop for maximum position |
| 3. Complete potentiometer casing | 7. Pedal travel limiting device |
| 4. Potentiometer connector | |



GLOW PLUGS

They are assembled on the cylinder head and have direct access to the combustion chamber.

Pre- and post-heating times are managed by the ECU according to the coolant temperature, as shown in the following tables.


Pre-heating time:

°C	-20	-10	0	20	50	90
sec	12	10	8	4	1,5	1

Distraction time: 10 sec

Post-heating time:

°C	-20	-10	0	20	50	90
sec	6	5	4	2	1	1



Glow plug absorption curve


Rated voltage: 11.0 V

Operating voltage: min 7.0 V - max 13.5 V

Absorbed current: max 30 A

Tighten on cylinder head to 15 Nm.

Tighten the supply cable fastening nut at 1.5 Nm.




SPEED SENSOR


It is assembled externally on the crankcase.

It reads the signal provided by the phonic wheel (60 - 2 teeth) integrated in the flywheel.


The air gap is 0.25 - 1.10 mm. It can be adjusted by means of shims of 0.5 mm.

**ELECTRIC FAN**

The electric fan activation is controlled by the control unit.
The electric fan current absorption cannot exceed 12 A.
If the electric fan and radiator are not supplied by Lombardini, they must receive the approval of Lombardini's Application Department.

**STARTER MOTOR****Features:**


type Bosch 12V
Power kW 1.1
Rotation direction clockwise




ALTERNATOR

External, belt-driven by crankshaft.
Rotation ratio: 1:1.6.

40A External alternator load curve graph



Measured after reaching thermal stabilization at 25°C and under constant voltage of 14 V.

HANDLING AND LIFTING

- Attach the engine to a suitable lifting device (lifting beam).
- Hook the lifting device in the engine lifting points, as shown in the figure.
- Before lifting, make sure the weight is correctly balanced by checking its barycentre.

**Important**

The bracket of the lifting points have been designed to lift the engine only. They are not intended nor approved to lift additional weights.

Do not use different methods to lift the engine than those described herein. In case different methods are used, no warranty shall be granted for any consequential damage.

ENGINE STORAGE

- When the engines are not for more than 6 months, they have to be protected performing the operations described in the following pages.
- If the engine is not to be used for extensive periods, check the storage area conditions and the type of packaging and make sure that these are suitable for correct storage.
If necessary, cover the engine with a proper protective sheet.
- Avoid storing the engine in direct contact with the ground, in environments that are humid and exposed to bad weather, near high voltage electric lines, etc.



Important

If, after the first 6 months, the engine is still not used, it is necessary to carry out a further measure to extend the protection period (see "Protective treatment").

PROTECTIVE TREATMENT

- | | |
|---|--|
| <ul style="list-style-type: none"> 1 - Pour in the engine housing AGIP RUSTIA C protective oil up to the maximum level. 2 - Fill up with fuel containing 10% AGIP RUSTIA NT. 3 - Make sure that the coolant is up to the maximum level. 4 - Start the engine and keep it idle at minimum speed for some minutes. 5 - Bring the engine to $\frac{3}{4}$ of the maximum speed for 5÷10 minutes. 6 - Turn off the engine. 7 - Empty out completely the fuel tank. 8 - Spray SAE 10W on the exhaust and intake manifolds. 9 - Seal the exhaust and intake ducts to prevent foreign bodies from entering. 10 - Thoroughly clean all external parts of the engine using suitable products. | <ul style="list-style-type: none"> 11 - Treat non-painted parts with protective products (AGIP RUSTIA NT). 12 - Loosen the alternator/fan belt. 13 - Cover the engine with a proper protective sheet. |
|---|--|



Caution - Warning

In countries in which AGIP products are not available, find an equivalent product (with specifications: MIL-L-21260C).



Important

Maximum every 24 months of inactivity, the engine must be started up by repeating all "Engine Storage" operations.

PREPARING THE ENGINE FOR OPERATION AFTER PROTECTIVE TREATMENT

After the storage period and before starting up the engine and preparing it for operation, you need to perform certain operations to ensure maximal efficiency conditions.

- | | |
|---|--|
| <ul style="list-style-type: none"> 1 - Remove the protective sheet. 2 - Remove any sealing devices from the exhaust and intake ducts. 3 - Use a cloth soaked in degreasing product to remove the protective treatment from the external parts. 5 - Inject lubricating oil (no more than 2 cm³) into the intake ducts. 6 - Adjust the alternator/fan belt tension. 7 - Turn the engine manually to check the correct movement and smoothness of the mechanical parts. 8 - Refill the tank with fresh fuel. 9 - Make sure that the oil and the coolant are up to the maximum level. 10 - Start the engine and after some minutes bring it to $\frac{3}{4}$ of the maximum speed for 5-10 minutes. 11 - Turn off the engine. 12 - Remove the oil drain plug (see "Oil replacement") and discharge the AGIP RUSTIA NT protective oil while the engine is hot. 13 - Pour new oil (see "Table of lubricants") up to the maxi- | <ul style="list-style-type: none"> mum level. 14 - Replace the filters (air, oil, fuel) with original spare parts. 15 - Empty the cooling circuit completely and pour in the new coolant up to the maximum level. |
|---|--|



Caution - Warning

Over time, a number of engine components and lubricants lose their properties, so it is important considering whether they need replacing, also based on age (see Replacement table).



Important

Maximum every 24 months of inactivity, the engine must be started up by repeating all "Engine Storage" operations.

RECOMMENDATIONS FOR DISASSEMBLY



Important

To locate specific topics, the reader should refer to the index.

- Before any intervention, the operator should lay out all equipment and tools in such a way as to enable him to carry out operations correctly and safely.
- Before proceeding with operations, make sure that appropriate safety conditions are in place, in order to safeguard the operator and any persons involved.
- In order to operate safely and easily, we recommend positioning the engine on a rotating stand for engine overhauling.




Caution - Warning

When installing the LDW 492 DCI engines, always bear in mind that any variation to the functional systems may involve serious failures to the engine.


Any improvement must be verified at Lombardini's testing laboratories before application of the engine.

In case the approval to a modification is not granted, Lombardini shall not be deemed responsible for any consequential failures or damages to the engine.




ENGINE WIRING HARNESS


Unscrew the 4 screws **A** and remove the acoustic insulation panel.




Disconnect the coolant temperature **P** sensor connector.




Release the safety lock **1** press on tab **2** and simultaneously disconnect the connector from the electronic injector **Q - N**.




Release the safety lock **3** press on tab **4** and simultaneously disconnect the connector **T** from the pressure regulator.




Release the safety lock **5** press on tab **6** and simultaneously disconnect the connector **R** from the pressure sensor.



Bring the speed sensor connector to an accessible position and then disconnect the connector **L** from the speed sensor by pressing on lock spring.




By pressing on lock spring **ALT** disconnect the alternator connector.



Disconnect the connector **H** from the oil pressure sensor.




Remove the engine wiring harness.



SERVICE WIRING HARNESS

Unscrew the fastening nuts and disconnect the supply cable of glow plugs **Cn1** and **Cn2**



11

Disconnect the connector **MOT** on the starter motor.



12

Remove the service wiring harness.



13


EXHAUST MANIFOLD

1. Unscrew the four fastening nuts and remove the manifold.
2. Remove the gaskets.
3. Close the openings and ducts to prevent foreign bodies from entering.



Important

Replace the self-locking nuts and the metal gaskets between the manifold and the cylinder head every time they are disassembled.



14

INTAKE SYSTEM AND DUCTS

1. Release the rubber clamp that fixes the air filter to the support.
2. Use the special pliers to open the clamp of the air filter/inlet manifold connection duct.



15



16

3. Disconnect the filter from the duct.
4. Use the special pliers to open the clamp and disconnect the vent duct from the oil vapours decanting device.




17

5. Simultaneously remove the intake duct and the oil vapours vent duct.



18


6. Remove the fastening screws and disassemble the air filter support bracket.



19


INLET MANIFOLD

1. Unscrew the two fastening screws **A** of the heat protection **B** and then remove it.
2. Unscrew the two fastening screws **C** and remove the manifold.
3. Remove the gaskets.
4. Close the openings and ducts to prevent foreign bodies from entering.



ALTERNATOR AND DRIVE BELT

1. Unscrew and remove the alternator fastening screw **A** and nut **B**.
2. Manually push the alternator upwards to loosen the belt.



3. Release the belt from the pulleys and remove the alternator.



4. Unscrew the fastening screws and remove the alternator support bracket.



FUEL SUPPLY HOSES - Disassembly



25

INJECTOR RETURN LINE

Push the split pin by its closed side against the return line fitting.



26


Keep the split pin in this position and disconnect the fittings from the injectors by pulling them upwards. Pay attention to the O-rings.



Caution - Warning

After removing the fittings, the split pin must automatically return to the normal position.

If this does not happen, replace the split pin.




27



Important

Seal all the openings of the return line and injectors, to keep dirt or foreign bodies out of the engine.



28


INJECTION PUMP SUPPLY HOSES

Press on the safety pawls **B** to disconnect the Diesel fuel delivery line.




29

Disconnect the injection pump return line.



30

Use the special plugs **C** to seal the fuel inlet and outlet holes.



31

OVERPRESSURE RETURN LINE


Disconnect the hose **D** from the Rail and use a special plug **E** to plug the union.



32

FUEL DISTRIBUTOR

Unscrew the fastening screws and remove the distributor with hoses and safety filter.



33


HIGH-PRESSURE LINE BETWEEN INJECTION PUMP AND RAIL

Unscrew the high-pressure line union F on the Rail.



Caution - Warning

When unscrewing the high-pressure line union that connects the pump to the rail, hold the union G on the high-pressure pump with a wrench.




34



Important

After disassembling the high-pressure line, use the special plugs to close the fuel passage holes on the high-pressure pump H and on the Rail L.




35

ELECTRONIC INJECTORS



Important

Before removing the injectors and/or the delivery hoses, mark them (0 and 1, see photo) not to reverse the original position of the cylinders during the reassembly phase. If the position of the electronic injectors is changed, the ECU will not detect the expected IMA codes. This will result in poor engine performances (see page 42).



36

HIGH-PRESSURE LINES OF THE INJECTORS




Caution - Warning

Unscrew the union of the high-pressure line M, by holding the injector union N with a wrench, then unscrew union O.




Caution - Warning

Carry out the high-pressure line disassembly with care to avoid damaging the cones and the sealing olives.



Caution - Warning

Seal the Rail outlets, injector union and high-pressure line inlets.



Extracting the electronic injectors from the cylinder head

- 1- Unscrew the screw 1 and remove the bracket 2 that fixes the electronic injector to the cylinder head.
- 2- Manually rotate the electronic injector in its seat to extract it. Make sure not to leave the copper gasket 3 in its seat on the cylinder head.



Important -



Warning

The protrusion of the nozzles from the cylinder head surface depends on the seal 3. Use seals of different thickness to obtain a different protrusion.


Match each seal with the corresponding injector.

Never use improper tools to extract the electronic injector from the cylinder head.



RAIL

Unscrew the two fixing columns of the acoustic insulation panel that fix the rail to the cylinder head.



Disassemble the Rail and remove the columns that fix it to the cylinder head.



41

GLOW PLUGS

Use a box wrench to loosen the glow plugs, to avoid damaging the hexagon.

Remove the glow plugs.




42

COOLANT OUTLET FLANGE AND THERMOSTATIC VALVE

1. Unscrew the three fastening screws and remove the coolant outlet flange **1** (coolant flow from engine to radiator).

2. Remove the thermostatic valve **2**



43

WATER TEMPERATURE SENSOR

Disassemble the sensor from its seat in the thermostat case and check the condition of the **O-ring**.



44

OIL FILTER CARTRIDGE


Use the special tool to disassemble the cartridge.



45

STARTER MOTOR

Unscrew the fastening screws and remove the starter motor.



46

ALTERNATOR DRIVE PULLEY

1. Insert the special tool 1 p/n 1460.301 in the threaded hole on the crankcase (flywheel side) to secure the crankshaft against rotation.



47

2. Unscrew the four fastening screws to remove the pulley.

TIMING SYSTEM

1. Unscrew the fastening screws and remove the external timing belt guard **A**.

Key to components:

- 1- Camshaft toothed pulley
- 2- Water pump
- 3- Tightening pulley
- 4- Timing system drive pulley




48

2. Unscrew the fastening screw of the tightening pulley **3** and manually rotate it to loosen the belt.
3. Remove the timing system drive belt **B**.



Important

Every time the belt is disassembled it must be replaced even if it has not reached the prescribed time for replacement.




49

4. Fit the special tool **1** p/n ED0014603900 to lock the camshaft timing pulley.
5. Unscrew the fastening bolt.




Caution - Warning

When removing the pulley, pay attention not to drop the key **2**.



50

6. Remove the timing pulley on the camshaft.



51

7. Unscrew the fastening bolt of the timing system drive pulley on the crankshaft.


8. Remove the timing system drive pulley on the crankshaft.



52

TIGHTENING PULLEY


Unscrew and disassemble the tightening pulley.



53

9. Unscrew the 3 fastening screws of the internal timing belt guard.

10. Disassemble the internal timing belt guard.



54


WATER PUMP

Unscrew the fastening screws and remove the water pump.



Important

The water pump cannot be repaired. In case of failure it must be replaced with a new one.




55

FLYWHEEL

1- Insert the special tool 1 p/n 1460.301 in the threaded hole on the crankcase to secure the crankshaft against rotation.

2- Unscrew the three fastening screws.

3- Remove the flywheel-locking tool 1 (1460.301).


Caution - Warning

During the disassembly phase, pay particular attention to the cylindrical reference pin 2 between the flywheel and the crankshaft.


- 4- Disassemble the flywheel paying attention not to damage the teeth of the phonic wheel 3.


SPEED SENSOR


Unscrew the two fastening screws and remove the speed sensor.


Important

After disassembling the sensor, protect it against shocks, humidity and any sources of high temperature.


STARTER MOTOR SUPPORT PLATE

Unscrew the three fastening screws to remove the plate.



59

HIGH-PRESSURE PUMP

Unscrew the nut and remove the fixing bracket of the high-pressure pump.



Caution - Warning

Pull out the pump, paying attention not to drop the roller tappet pad.




Important

The roller tappet pad B (fig.60) is available in different thicknesses, since it determines the injection pump pre-stroke.

When replacing the injection pump, the pad thickness has to be determined again.

To determine the correct thickness of pad B (fig.60) refer to page 91.




60

High-pressure pump - Components

- A Roller tappet
- B Roller tappet pad
- C High-pressure pump
- D Seal
- E Locating pin seat
- F Locating peg

To disassemble the roller tappet refer to page 66.




CAMSHAFT COVER

Loosen the fastening screws shown by the arrows and disassemble the camshaft cover.



Important

In case of breakage or deformation of the camshaft cover, replace the whole cylinder head.




CAMSHAFT

Key to components:

- 1 High-pressure pump cam
- 2 High-pressure pump
- 3 Camshaft bearings
- 4 Intake cam
- 5 Exhaust cam
- 6 Seal ring



Remove the key and the oil seal ring.



Unscrew the recessed hex-head screw **A** to disassemble the roller tappet.



65




ROCKER ARMS AND HYDRAULIC TAPPETS

Disassemble the rocker arm and the hydraulic tappet by pulling the rocker arm upwards.

The hydraulic tappet comes off together with the rocker arm, since it is fixed to it by means of a clamp **2**.

In case the tappet does not come off with the rocker arm, extract it from its seat using pliers.




66

Key to components:

1. Rocker arm
2. Tappet fastening clamp
3. Hydraulic tappet

➡ For further specifications on the hydraulic tappet, refer to page 87.



67


CYLINDER HEAD



Important

Do not disassemble the head while the engine is hot, to avoid the risk of deformations.

Unscrew the fastening bolts on the cylinder head following the order shown in the photo.




68

Remove the cylinder head and place it in a suitable container to wash it thoroughly.



Important

The cylinder head fastening bolts must be replaced at each disassembly.



69

CYLINDER HEAD GASKET

Remove the gasket.



Important


The head gasket must be replaced every time it is disassembled.



70

GEAR COVER

Unscrew the fastening screws and disassemble the cover, paying particular attention not to damage the oil seal ring **5**, shown in fig.71.



71


Key to components:

1. Balance shaft gear drive gear
2. Balance shaft gear
3. Oil pump
4. O-ring
5. Oil seal ring



Important


Check the integrity of the O-ring (4) and replace it if necessary.



72

OIL PUMP GEAR

Unscrew the torx screw and pull the gear out.




73

OIL PUMP

Unscrew the four fastening screws and remove the oil pump plate.

The trochoid oil pump is driven by the balance shaft. The pump casing is partly integrated in the engine block, and partly in the crankcase.



74

OIL SUMP

Unscrew the fastening screws and remove the oil sump.

Components:

- 1 Oil suction pipe
- 2 Oil sump return line from vent system
- 3 Oil pressure regulating valve



75

CONNECTING ROD BIG END CAPS

- 1. Rotate the crankshaft to bring it to the bottom dead centre.
- 2. Unscrew the big end cap screws using a torx wrench.



76

- 3. Disassemble the connecting rod big end caps.



Important

The connecting rod half-bearings are made of special material. Therefore, they must be replaced every time they are removed to avoid seizures.



Important

During the reassembly phase, the two centring pins F on the connecting rod cap must coincide with the special holes F on the big end.



77

PISTON


Press by hand on the connecting rod big end to pull out the connecting rod - piston assembly.



78

**Important**


Mark some references on the connecting rods, caps, pistons and gudgeon pins to avoid unintentionally mixing up the components during the reassembly phase, since this could result in engine malfunctioning.



79

CRANKCASE

Remove the screws shown by the arrows to separate the upper and lower crankcase.



80


Remove the lower crankcase and place it in a suitable container to wash it (see fig.84).

**Caution - Warning**

When disassembling the lower crankcase, pay attention not to damage the crankshaft half-bearings and the components of the oil pressure regulating valve A.

**Important**


The connecting rod half-bearings are made of special material. Therefore, they must be replaced every time they are removed to avoid seizures.



81

BALANCE COUNTERSHAFTS

1. Remove the balance shaft together with the oil pump lobes.



82

2. Remove the second balance shaft with the gear.



83


CRANKSHAFT

Remove the crankshaft with the gear.



Important

The connecting rod half-bearings are made of special material. Therefore, they must be replaced every time they are removed to avoid seizures.



84

ENGINE BLOCK

Place the engine blocks in a container suitable for washing.

RECOMMENDATIONS FOR OVERHAULS AND TUNING

- Information is given in a logical order in terms of timing and sequence of operations. The methods have been selected, tested and approved by the manufacturer's technical experts.
 - This chapter describes procedures for checking, overhauling and tuning assemblies and/or individual components.
 - Wash the components with special detergent and do not use steam or hot water.
 - Do not use flammable products (petrol, diesel, etc.) to degrease or wash components. Use special products.
 - Dry all washed surfaces and components thoroughly with a jet of air or special cloths before reassembling them.
 - Apply a layer of lubricant over all surfaces to protect them against oxidation.
 - Check all components for intactness, Wear limit, seizure, cracks and/or faults to be sure that the engine is in good working condition.
 - Some mechanical parts must be replaced *en bloc*, together with their coupled parts (e.g. valve guide/valve etc.) as specified in the spare parts catalogue.
- Important**
- To locate specific topics, the reader should refer to the index.**
- Before any intervention, the operator should lay out all equipment and tools in such a way as to enable him to carry out operations correctly and safely.
 - The operator must comply with the specific measures described in order to avoid errors that might cause damage to the engine.
 - Before carrying out any operation, clean the assemblies and/or components thoroughly and eliminate any deposits or residual material.

Shaft seals

- Clean the shaft thoroughly and make sure that it is not damaged or scored or become oval-shaped in the areas of contact with the seals.
- Do not use a hammer directly on the gaskets during assembly, to avoid damaging them.
- Lubricate the seal lips, and pointing them in the right direction, place them in their seat using a special pad.
- Be careful not to damage the gaskets while joining them to the shaft.


O- rings

- Lubricate the seal before introducing it to its seat.
- Avoid «rolling» the gasket during the attachment phase.

OVERHAULING THE CRANK GEARS AND CRANKCASE

Overhauling cylinders and pistons

Before deciding what kind of overhaul needs to be done, it is important to carry out a dimensional check and verify the correspondence of cylinders, pistons, sealing rings, crankshaft and connecting rods.



85


PISTON

1. Disassemble the lock ring **B**.
2. Pull out the gudgeon pin **C** to separate the piston **D** from the connecting rod **E**.




Important

Keep each connecting rod coupled with its piston and gudgeon pin.



86

3. Disassemble the seal rings **F**.



87

Clean the piston thoroughly.

Using a micrometer, measure the piston 12 mm from the skirt base. Check the table to identify the class of the measured values.

The class letter is engraved on the piston crown.


If clearance between cylinder and piston is greater than 0.05 mm, the piston and seal rings must be replaced.



Important

Before replacing the pistons, check that the weight difference between the two integral preassembled connecting rod/piston/gudgeon pin assemblies does not exceed 8 g, to prevent weight imbalances.

Protect the contact surfaces with lubricating oil, to prevent them from rusting.



88

Using a thickness feeler gauge, measure the clearance of each seal ring in its seat.

If the clearance does not comply with the values shown in the table, replace the seal rings and piston with original spare parts.


Seal rings/Piston clearance table

Seal rings	Clearance (mm)
1°	$L1 = 0,070 \div 0,105$
2°	$L2 = 0,050 \div 0,085$
3°	$L3 = 0,025 \div 0,070$



Important

- Seal rings cannot be replaced separately.
- Protect the contact surfaces with lubricating oil, to prevent them from rusting.



89

CYLINDERS

Place the engine block on the workbench.

Using a dial gauge, measure the diameter at points 1-2-3 (see figure).

Rotate the dial gauge 90° and re-measure.

Check the table to identify the class of the values measured.

The class letter is engraved on the engine block (see figure).

If ovalization or wear is greater than 0.05 mm, the cylinder must be reconditioned.



Important

- The cylinders can be oversized by 0.25 and 0.50 mm, in compliance with the Manufacturer's specifications.
- When reconditioning, make sure that the working angle is 45°-55° and that the average roughness is $Ra=0.25 \div 0.5$.
- Do not finish the internal surface of the cylinders using an emery cloth.
- Protect the contact surfaces with lubricating oil, to prevent them from rusting.

Cylinders/Pistons dimension and class table


Dimensional Class	Cylinder Ø (mm)	Piston Ø (mm)	Clearance (mm)
B	69,00÷69,01	68,96÷68,97	0,03÷0,05
C	69,01÷69,02	68,97÷68,98	

This table shows the reference values and their classification (only valid for new engines).



Important

Pistons having a diameter as per their nominal value are supplied as spare parts only for class (B). The oversized ones (0.25 and 0.50 mm) have a reference (Ø 68.25 and Ø 68.50) engraved on the upper section (crown) of the piston.



90


RINGS

Place a seal ring in the cylinder and measure the ring end gap using a thickness gauge (**H**). Repeat for all the seal rings.

If the ring end gap does not correspond to the values indicated in the table, replace the seal ring with an original spare part.

Seal ring dimensional table

Seal rings	Ring end gap (mm)	Wear limit (mm)
1°	0,25÷0,40	0,95
2°	0,30÷0,50	1,05
3°	0,25÷0,50	1,05



91

Install the seal rings on the piston in the order shown in the figure.




Important

Set the seal rings with their marking turned towards the piston crown.



Important

Protect the contact surfaces with lubricating oil, to prevent them from rusting.



92

CRANKSHAFT

Dimensional check and overhauling

Wash the crankshaft thoroughly using suitable detergent.

Introduce a pipe cleaner into the lubrication ducts to remove any residual dirt.

Use a jet of compressed air to thoroughly clean the oil passages.

Check the surfaces of the main journals and crankpins for Wear limit to see whether grinding is necessary.

Using a micrometer, measure the diameter of the main journals (**A1**) and crankpins (**B1**).

Couple the engine block with its crankshaft half-bearings and tighten to the specified torque (see page 105). Using a dial gauge, measure the internal diameter of the crankshaft and connecting rod half-bearings (**A1** and **B2**).

The gear on the crankshaft is timed by means of a key and installed after heating at a stabilized temperature of 180°C for 5 minutes.

Connecting rod and crankshaft half-bearings - Diameters

Rif.	Dimensions (mm)	Wear limit (mm)	Clearance (mm)	Max clearance (mm)
A1	47,984÷48,000	47,96	A2-A1 = 0,019÷0,081	0,12
A2	48,019÷48,065	48,08		
B1	38,984÷39,000	38,97	B2-B1 = 0,027÷0,072	0,10
B2	39,027÷39,056	39,07		



Important

Protect the contact surfaces with lubricating oil, to prevent them from rusting.



Important


- Half-bearings cannot be replaced separately.
- If it is necessary to grind the crankshaft, define the diameters of the main journal and crankpin to choose the available coupling measures for the new crankshaft and connecting rod half-bearings (see table "Connecting rod and crankshaft half-bearings - Diameters").
- When grinding the crankshaft it is possible to undersize the main journals and crankpins by 0.25 and 0.50 mm.



Caution - Warning

The crankshaft and connecting rod half-bearings are made out of special lead-free material, and hence must strictly be replaced with new ones every time they are removed in order to prevent seizure.

Protect the contact surfaces with lubricating oil, to prevent them from rusting.



93

CRANKSHAFT - Axial clearance check


To measure the axial clearance of the crankshaft, it is necessary to assemble the shaft in the crankcase complete with engine block. See "Assembling the crankcase" on page 92 for the correct procedure.

Using a dial gauge, measure the axial shift of the crankshaft. Axial shift must be between 0.10÷0.22 mm.




Important

If the axial clearance between the crankshaft and the crankcase is above 0.60 mm, it is necessary to replace the whole engine block.



BALANCE COUNTERSHAFTS - Pin housing diameters

Couple the two engine blocks and tighten to the specified torque (see on page 92). Using a dial gauge, measure the pin housing internal diameters (1 and 2), see "Table for determining countershaft housing and pin clearance".




Check the pin surfaces for Wear limit and integrity.

Use a micrometer to measure the pin diameter (3 and 4).

Check in the following table the pin clearance.
If the resulting clearance does not comply with the specified tolerances, replace the balance shaft or the engine blocks.

Table for determining countershaft housing and pin clearance

	Balance shaft pin	Balance shaft housing	Clearance	Wear limit
Timing system side (1-3)	30,955÷30,940	31,000÷31,025	0.045÷0.085	0,100
Flywheel side (2-4)	27,955÷27,940	28,000÷28.021	0.045÷0.081	0,960



CONNECTING ROD - Dimensional check and overhauling


Check that the contact surfaces are perfectly clean and intact.



Caution - Warning

The crankshaft and connecting rod half-bearings are made out of special lead-free material, and hence must strictly be replaced with new ones every time they are removed in order to prevent seizure.

Assemble the cap (N) on the big end together with the new half-bearings and then tighten the screws to a torque of 25 Nm.
Using a dial gauge, measure the diameters C - B.




97

Connecting rod dimension table

Rif.	Dimensions (mm)	Clearance (mm)	Wear limit (mm)
A	110,98÷111,02	B - D 0,025÷0,04	0,07
B	20,025÷20,035		
C	19,995÷20,000		
D	39,027÷39,056		
E	43,8÷44,0		

**Important**

- Make sure that the connecting rod and crankshaft half-bearings are properly matched (see "Table of crankshaft and connecting rod half-bearing dimensions").
- The connecting rod half-bearings are supplied with undersized dimension, with respect to the nominal dimension of 0.25 mm e 0.50 mm.
- If the small end (B) diameter does not perfectly match with the one of the gudgeon pin (D), it is necessary to replace the small end bearing to obtain the correct coupling (see "Connecting rod dimension table").
- Protect the contact surfaces with lubricating oil, to prevent them from rusting.



98


CONNECTING ROD

Check of axis parallelism

Insert the gudgeon pin in the connecting rod small end. Use a dial gauge to check the axis parallelism of the connecting rod big end and small end. Parallel deviation, measured at the very tip of the gudgeon pin, must not exceed 0.015÷0.030 mm. If the measured values do not comply with the specified ones, replace the connecting rod with an original spare part. Before replacing the connecting rods, check that the weight difference between the two integral preassembled connecting rod/piston/gudgeon pin assemblies does not exceed 8 g, to prevent weight imbalances.

**Important**

Protect the contact surfaces with lubricating oil, to prevent them from rusting.



99



Important

Before carrying out the pre-assembly, check that the weight difference between the two connecting rod/piston/gudgeon pin assemblies does not exceed 8 g, to prevent weight imbalances.

Lubricate the gudgeon pin (A) and the seat of the small end of the connecting rod (B).

Install the lock ring (C) on the piston complete with seal rings (D).



Important

Insert the lock rings with their tips turned towards the piston base (15° tolerance).

Insert the gudgeon pin (A) in the piston (D) and assemble the connecting rod (B) (complete with cap (E)).

Insert the gudgeon pin completely and fasten it with the second lock ring (C).



Important

Check that the lock rings are correctly housed in their seats. Lubricate the coupling surfaces and the ones that are prone to oxidation.



100

CLEARANCE VOLUME

Position the pistons at the top dead centre.

Measure the distance from the piston crown to the crankcase surface in four diametrically opposite points.

Repeat the operation on all pistons.

The maximum measured value determines the value (A).

According to the measured value, choose the most suitable gasket.

This choice determines the value of the clearance volume (see "Head gasket selection and clearance volume table").

Head gasket - Determining the thickness

After determining the value A and identifying the correct head gasket, assemble it referring to the centring pins.



101



Important

The head gasket must be replaced every time it is disassembled.

Head gasket selection and clearance volume table


A (mm)	Number of holes		Clearance volume (mm)
0,280÷0,380	1		0,340÷0,440
0,381÷0,480	2		0,340÷0,439
0,481÷0,580	3		
0,581÷0,680	4		



102

VAPOUR RECIRCULATION VENT

Unscrew the four fastening screws of the cover and remove it.



103

Vapour recirculation vent - Operating principle


The vapours are discharged through the duct **A** and then reach the first decanting chamber **X**.

The function of the metal filter element **B** is to slow down the vapours in order to let them condense.

The drops of condensed oil, having a greater specific weight than the vapours, flow back to the oil sump trough the same duct **A**.

The vapours then pass from the decanting chamber **X** to the chamber **Y** through a labyrinth that allows for further condensation.

The vapours now condensed flow back to the sump through the hole **D**. The vapour left will be conveyed trough the duct **E** to the inlet manifold.




104

The reed valve **C**, that opens and closes according to the piston alternate motion, allows for maintaining a constant vacuum inside the engine block.

Check the seal of the valve **C**. If sealing is not perfect, replace the whole vent cover.

Wash the filter element **B** or replace it if completely clogged.

Check that the oil recovery hole **D** is not clogged.



105

VAPOUR RECIRCULATION VENT




Important

When reassembling, always replace the gasket **G.**

Insert the metal filter element **B** in its housing and reinstall the cover of the vapour recirculation vent.

- Tighten the screws to a torque of 10 Nm.




106

OIL PUMP


To overhaul and check the oil pump proceed as follows: disassemble the plate **A**, disassemble the rotors, thoroughly clean all the components and check for Wear limit of the working surfaces (rotors and pump casing in the crankcase) by referring to the relevant table for the values.

Install the rotors with the references **B** turned towards the installer.



107

Rotor seat diameter "B"	70,40÷70,43
Rotor external diameter "A"	69,95÷70,00
Seat - Rotor clearance "C"	0,40÷0,48
Rotor height "D"	6,98÷7,00
Rotor seat depth "E"	7,020÷7,045
Side clearance between rotors and pump casing "F"	0,020÷0,065
Radial clearance between rotors "G"	0,176



108

Using a thickness gauge, measure the clearance between the rotor teeth.


If clearance is above the 0.250 mm limit for wear, replace the rotors with original spare parts.

Check that the contact surfaces are perfectly clean, intact and not deformed.

OIL PRESSURE RELIEF VALVE


Key to components

- 1. Plug
- 2. Spring
- 3. Piston





109

The oil pressure relief valve is located in the lower crankcase.
 Unscrew plug **4**, pull out spring **5** and piston **6**



110






111

CYLINDER HEAD AND COMPONENTS - Overhauling

Valve disassembly

- 1 - Place the cylinder head on the workbench.
- 2 - Press hard on the valve collar (A) using the special tool.
- 3 - Disassemble the cotters (B) that secure the cup (A), the spring (C), the cup (D) and the seal (E).




112

- 4 - Pull out the valves.



Important

When disassembling the valves, keep the components of the different valves together to allow correct reassembly of the valves.



113


VALVE SPRINGS

Use a gauge to measure the free length.
As shown in the figure, apply two different weights to the spring and check with a dynamometer that the values comply with the ones below.

Free length Z = 45.7 mm

Length Z1
compressed by a force of 20.4 kg = 27.2 mm

Length Z2
compressed by a force of 34.8 kg = 34.8 mm



114


Flatness check

Place the cylinder head on a surface plate and position it with the corners on the stud bolts.
Use a dial gauge to check the cylinder head levelness.



Important

If the level deviation is greater than 0.10 mm, the cylinder head must be ground, removing no more than 0.20 mm.



115

Valve seats - Check

Thoroughly clean the valves and their seats.

Measure the width of the seal (**J**) for each valve and the indentation (**W**) from the cylinder head surface (see "Valve stem/Valve guide dimension table").

If the dimensions measured do not match with the above-mentioned values, replace using original spare parts.

Use a pointed tool to take out the valve seats.

Remove any debris, clean the valve seat housing carefully and scrape the opening.

Lubricate the new valve seats and put them into the housing manually.

Use the special tool to put the valve seats into the housing.

Slide the valves into their seats.

Measure the degree of indentation of each valve with respect to the cylinder head surface (see "Valve stem/Valve guide dimension table").

If the measured values do not comply with the specified ones, grind each valve in its seat.




Important

Since the seats are prefinished, they are not to be worked again after they have been driven in the head.



Important

Protect the contact surfaces with lubricating oil, to prevent them from rusting.



116

Valve guides - Overhauling and Check

Use a micrometer to measure the diameters of the valve stems **C** and a dial gauge to measure the valve guide diameters **B** (see "Valve stem/Valve guide dimension table").

If the diameters do not comply with the specified ones, replace the valves and guides with original spare parts.

After being driven, the intake and exhaust valve guides must result receding, with respect to the rocker arm support surface, by the value shown in the "Valve stem/Valve guide dimension table".




Important

Carry out the measurements in different points to detect any ovalization and/or concentrated wears.

Valve stem/Valve guide dimension table

Rif.	Dimensions (mm)	Clearance (mm)	Wear limit (mm)
ØB	6,005÷6,020	B - C 0,015÷0,06	0,10
ØC	5,978÷5,990		
A	57,3÷57,7		
W	0,6÷0,9		1,2
J	1,3÷1,4		1,75



117


Valves guides and housings

The intake and exhaust guides are both made out of gray iron with pearlitic phosphoric matrix and they have the same dimensions:

Dimensions (mm):

D	E
10,045÷10,054	10,000÷10,018

Note: Since the guides are prefinished, they are not to be worked again after they have been driven in the head.



118


VALVES - Reassembly



Important


- Check that the cylinder head has been perfectly washed and dried.
- Check that all components are intact and, if necessary, replace them with original spare parts.

- 1 - Generously lubricate the valve stem seal ring (A) and then fully insert it on the valve guide using the tool "717-1460-047".
- 2 - Lubricate the valve stem (B).
- 3 - Slide the valve into its seat.



119

- 4 - Assemble the cup (C), spring (D), collar (E) and cotter (F).
- 5 - Press hard on the collar (E) using the special tool to insert the cotter (F) into the valve stem opening.
- 6 - Release the tool and check that the cotter are correctly positioned. If the cotter are not correctly positioned, repeat the operation.
- 7 - Repeat the same operation on the other valves.



120


Glow plug specifications and injector protrusion

Description	Value
Operating voltage	11 V
Voltage range	7÷13.5 V
Performance	Single pole
Current	Max 30A

TIMING SYSTEM

Components:

- 1 Hydraulic tappet
- 2 Rocker arm
- 3 Rocker arm pin
- 4 Camshaft
- 5 Valve
- 6 Cylinder head
- 7 Lubrication line



121

Timing angle scheme




Important

For information purposes, the timing angle values are provided below.


It must be pointed out that such values are not measurable on the engine because of the presence of the hydraulic tappets. They can be checked only when machining the camshaft.

Timing angle diagram:

- $\alpha = 4^\circ$ before S (top dead centre)
- $\beta = 32^\circ$ after I (bottom dead centre)
- $\gamma = 58^\circ$ before I (bottom dead centre)
- $\delta = 6^\circ$ after S (top dead centre)



122



HYDRAULIC TAPPET

Components:

- 1 Tappet body
- 2 Low pressure piston
- 3 High pressure piston
- 4 Spring
- 5 Non-return valve
- A Low-pressure chamber
- B High-pressure chamber


The operating principle of the hydraulic tappet is based on the incompressibility of liquids and on controlled leakage. The oil under pressure enters the tappet chamber **A**, providing a constant supply of oil in the low-pressure chamber. The oil can only enter the high-pressure chamber **B** through the non-return valve **5** and leave via the clearance between the piston **3** and the tappet body **1** (controlled leakage). The chamber **B** is filled when the rocker arm is on the base radius of the cam, and the spring **4** keeps the piston **3** against the valve stem, thus eliminating any system plays. Because of the spring extension, the tappet "extends", thus creating a small depression in the chamber **B**. Such depression makes the non-return valve **5** open, thus allowing the oil in the chamber **A** to pass to chamber **B** to restore the correct oil quantity necessary to eliminate any plays in the valves.

Difficult operating conditions:

For correct operation of the hydraulic tappets, the pressure chamber of piston **3** must always be filled with oil. Under certain conditions this may not happen, since oil leakage, with engine stopped, can lead to complete emptying of the tappets. This will result in valve plays entailing a characteristic sound, like a ticking, not to be confused with the normal ticking of the injectors.


- 1 - With cold engine, the tappet filling time could be very long if the oil used is not suitable for the specific environmental conditions (see prescribed oil on page 21).
- 2 - When the engine is hot, oil pressure may be low when running at idle, and small air bubbles could form up in the circuit. Because of this, the lubricant becomes compressible, thus compressing the tappet and producing a valve play which is responsible for the ticking sound.

However, the ticking sound should not last more than 5 minutes. If this is not the case, the problem is surely due to the insufficient oil level, to Wear limit or to clogging of the ball valve and its seat in the piston preventing the tappet from operating correctly. In this case, the only solution is to change the oil and replace the hydraulic tappets.



CAMSHAFT COVER - INSPECTION

Unscrew the plug **A M6** together with gasket.
Insert special tool **B** cod. ED0014603910 insert the side **1** of the tool.
Keeping pressed the special tool **B** rotate the crankshaft with the wrench **C** til the special tool **B** will be completely inside of the camshaft hole **D Ø3**.



After the holes(**A M6** and **D Ø3**), tighten special tool **B** side **2** at a torque of 8 Nm.
Now the camshaft **E** is locked.



Disassemble camshaft cover **F** for inspection




Important

Do not remove the special tool B before reassemble camshaft cover.

Reassemble camshaft cover with sealant, camshaft reassemble procedure described on pag. 102.

Remove the special tool **B** and reassemble the plug **A M6** together with gasket.

- Tighten the plug **A M6** at torque of 10 Nm.



CAMSHAFT

Before measuring the camshaft housings **X** on the cylinder head, couple the camshaft bearing **Z** and the cylinder head and tighten to a torque of 10 Nm, following the order shown in the figure.




Important

Failure to perform a proper tightening could result in breakage or deformation of the camshaft bearing.



Important

The camshaft bearing is machined on the basis of the cylinder head to which it is coupled. Therefore, it cannot be supplied separately.




Use a dial gauge to measure the diameters of the housings (**X**) and a micrometer to measure the diameters of the camshaft (**Y**) (see "Table of camshaft dimensions").

Table of camshaft dimensions

Rif.	Dimensions (mm)	Clearance (mm)	Wear limit (mm)
ØX	25,035÷25,060	ØX - ØY = 0,035÷0,081	0,150
ØY	24,979÷25,000		

If the diameters do not comply with the specified values, replace the camshaft or the cylinder head with an original spare part.



Important

In case of breakage or wear of the camshaft cover, replace the whole cylinder head.

Use a micrometer to measure the maximum dimensions of the involutes of the intake, exhaust and high-pressure pump cams (see "Table of cam dimensions").

- A Intake cam
- B Exhaust cam
- C High-pressure pump cam

If the dimensions of cam involutes are lower than the values shown by 0.1 mm (maximum dimension), replace the camshaft with an original spare part.



Important


Protect the contact surfaces with lubricating oil, to prevent them from rusting.

Assemble the camshaft on the cylinder head and check that the axial clearance is 0.05÷0.20.

If the axial clearance does not comply with this value, replace the cylinder head or the camshaft.

Table of cam dimensions

Rif.	Ø Dimensions (mm)
A	33,738÷33,763
B	33,542÷33,567
C	23,950÷24,000
C1	35,350÷35,400



130

HIGH-PRESSURE PUMP

Determining the thickness of the injection pump pad

➡ Refer to page 24 for the characteristics.

- A Position of the pump pre-stroke code number
- B Position of the plate on the high-pressure pump




Caution - Warning

The importance of determining the correct thickness of the pad between the tappet and the injection pump is due to the fact that such thickness represents the pre-stroke value of the high-pressure pump. An incorrect pre-stroke value will prevent reaching the correct fuel pressure and delivery values in the Common Rail.

Key to components:

- A Pump seal
- B Cylinder head
- C Pad
- D Roller tappet
- E Camshaft
- F Distance value between pump level and pad



131



132

1. Position the cam moving the high-pressure pump on its base radius, as shown in fig.131.
2. Measure by a depth gauge the value of quote **f**, without the gasket **A**, injection pump plan between head and the pad.



133

Depending on the pre-stroke code shown on the injection pump (0, +1, +2, +3) choose the pad as per the table below. For any inspection, the quote f (without gasket) must be within the values indicated in the table.

Table for determining the correct pad

Injection pump	0	+1	+2	+3
Pad thickness selection	4,5	4,4	4,3	4,2
Quote f to be controlled (without gasket)	44,00 ÷ 43,78	44,10 ÷ 43,88	44,20 ÷ 43,98	44,30 ÷ 44,08
Rated value	(43,89)	(43,99)	(44,09)	(44,19)

RECOMMENDATIONS FOR REASSEMBLY

- The instructions are provided in a sequential way, following a practical and chronological order. The working methods have been selected, tested and approved by the Manufacturer's technicians.
- This chapter describes all the installation procedures for assemblies and /or single components after overhauling, testing and, if necessary, replacement using original spare parts.



Important

To locate specific topics, the reader should refer to the index.

- The operator must wash, clean and dry components and assemblies before installing them.
- The operator must make sure that the contact surfaces are intact, lubricate the coupling parts and protect those that are prone to oxidation.
- Before any intervention, the operator should lay out all equipment and tools in such a way as to enable him to carry out operations correctly and safely.
- In order to operate safely and easily, we recommend positioning the engine on a rotating stand for engine overhauling.
- Before proceeding with operations, make sure that appropriate safety conditions are in place, in order to safeguard the operator and any persons involved.
- In order to fix assemblies and/or components correctly, the operator must tighten the fastening elements in a criss-cross or alternating pattern.
- For assemblies and/or components having a prescribed tightening torque, first tighten to a lower torque, then carry out the final torque to the prescribed value.



134

UPPER CRANKCASE

Crankshaft half-bearings

Thoroughly clean the main bearings and install the new half-bearings.



Important


- The central two semi-bearing **A** does not have the lubrication groove, while the four side have the lubrication groove.
- The half-bearings cannot be replaced separately.
- If it is necessary to grind the crankshaft, define the diameters of the main journal and crankpin to choose the available coupling measures for the new crankshaft and connecting rod half-bearings (see table "Connecting rod and crankshaft half-bearings - Diameters").
- When grinding the crankshaft it is possible to undersize the main journals and crankpins by 0.25 and 0.50 mm.



Caution - Warning

The crankshaft and connecting rod half-bearings are made out of special lead-free material, and hence must strictly be replaced with new ones every time they are removed in order to prevent seizure.

Once installed, generously lubricate the three half-bearings.




135



CRANKSHAFT

Lubricate the main journals, the half-bearings and assemble the crankshaft.

The gear on the crankshaft is timed by means of a key and installed after heating at a stabilized temperature of 180°C for 5 minutes.



BALANCE COUNTERSHAFTS


Lubricate the contact surfaces and assemble the first balance countershaft.

The gear on the balance shaft is timed by means of a key and installed after heating at a stabilized temperature of 180°C for 5 minutes.




Important

Carry out the timing of the balance countershaft gear and crankshaft gear by aligning the two references on the gears.



Thoroughly clean and lubricate the bearings of the second balance countershaft.


Assemble the second balance countershaft.



139

OIL PUMP - Lobes

The second countershaft controls the trochoid-type lobe oil pump. Insert the inner lobe by making the key **A** of the shaft coincide with the slot **A** of the lobe.




140



Important

The outer lobe must be installed with its reference **B** turned towards the installer.



141

LOWER CRANKCASE

Lower crankcase half-bearings

Thoroughly clean the lower crankcase main bearings and install the half-bearings.

Once installed, generously lubricate the three half-bearings.



Important


The central two semi-bearing **A** does not have the lubrication groove, while the four side have the lubrication groove.

The O-rings on the three centring bushes must be replaced before coupling the lower and upper crankcases.




Caution - Warning

The crankshaft and connecting rod half-bearings are made out of special lead-free material, and hence must strictly be replaced with new ones every time they are removed in order to prevent seizure.



142



143

Spread a thin layer of sealant on the sealing surface of the lower block, see the gray area of the scheme **A**, strictly avoiding areas of grooves **B**.



Caution - Warning

An excessive application of sealant may obstruct the passages of the lubrication channels.



144

CRANKCASE - Fastening

When coupling the lower and upper crankcases, pay particular attention not to damage the **O-rings** on the three centring bushes.



Important

Pay attention to the oil pressure relief valve: if previously installed, during the lower crankcase assembly, it may protrude from its seat.



145

Tighten the lower and upper crankcase fastening screws. Strictly follow the order shown and keep to the prescribed torque values.

Bolt tightening torques:

- 1) Bolts M 10x1.5 : 50 Nm (1-2-3-4-5-6)
- 2) Bolts M 8 : 25 Nm (7-8-9-10)
- 3) Bolts M 6 : 10 Nm (11-12-13-14).

PHASE 1

Tighten all the bolts to a torque of 10 Nm, following the order shown in the figure.

PHASE 2

Tighten all the bolts to a torque of 25 Nm, except for the M6 bolts (11-12-13-14).


PHASE 3

Tighten the bolts (from 1 to 6) to a torque of 50 Nm.



Important

Non compliance with the assembly specifications may result in crankshaft blocking.



146



147

OIL PUMP - Plate


Generously lubricate the lobes and the delivery and suction pockets of the oil pump, then assemble the plate.



148


Tighten the plate screws in a criss-cross pattern.

- Tighten the screws to a torque of 10 Nm.



149

Install the balance shaft gear, by making its reference **1** coincide with the one of the crankshaft gear **2**, and the key **3** of the balance countershaft.




150



Caution - Warning

Insert the centring washer **A** before tightening the screw.

- Tighten the screw to a torque of 60 Nm.



PISTON / CONNECTING ROD / GUDGEON PIN - Assembly

Check that the order of the references **R**, marked during the disassembly phase, matches the cylinder where the assembly (connecting rod, piston, gudgeon pin) is going to be installed, see on page 70.

Generously lubricate the cylinder, rings and connecting rod bearings.



Caution - Warning

The crankshaft and connecting rod half-bearings are made out of special lead-free material, and hence must strictly be replaced with new ones every time they are removed in order to prevent seizure.



After disassembling the connecting rod cap, slide the pistons in the cylinder paying attention to the correct positioning of the combustion chamber.




Caution - Warning

In order not to damage the seal rings and the contact areas while inserting the piston into the cylinder, use the special piston ring compression tool.



The combustion chamber on the piston crown must be positioned so as to have its decentralized part towards the water pump side.



CONNECTING ROD CAP

Generously lubricate the connecting rod caps and then assemble them making the two centring pins **B** on the cap coincide with the special holes **A** on the big end.




Caution - Warning

The crankshaft and connecting rod half-bearings are made out of special lead-free material, and hence must strictly be replaced with new ones every time they are removed in order to prevent seizure.

**Important**

The screws of the connecting rod caps must be tightened in an alternating pattern until reaching the prescribed torque value.

- Tighten the screws to a torque of 25 Nm.

**OIL SUMP**

Oil sump return line from vent system

**Important**


Always replace the O-ring (A) between the pipe and the lower crankcase any time the pipe is disassembled.

- Tighten the screw to a torque of 10 Nm.

**OIL SUCTION PIPE****Important**

Always replace the O-ring (A) between the pipe and the lower crankcase any time the pipe is disassembled.


- Tighten the screw to a torque of 10 Nm.



The seal of the oil sump plan (C) must be performed on the lower block distributing a bead of silicone sealant liquid.


**Caution - Warning**

An excessive application of sealant may obstruct the passages of the lubrication channels.



Tighten the oil sump screws following the prescribed order, to avoid the risk of deformation and oil leakages in the future.


- Tighten the screws to a torque of 10 Nm.



STARTER MOTOR SUPPORT PLATE

Reassemble the starter motor support plate.

- Tighten the screws to a torque of 25 Nm.



SPEED SENSOR


It reads the signal provided by the phonic wheel (60 - 2 teeth) integrated in the flywheel.

The shim **A** allows modifying the air gap ($0.25 \div 1.10$) between the sensor and the phonic wheel, by means of 0.5 mm shims.

The thickness can be removed without removing completely the screws of the sensor, forcing the bumps with forceps (**B**).

- Tighten the screws to a torque of 6 Nm.






FLYWHEEL

Assemble the flywheel on the crankshaft by making the cylindrical pin 2 coincide with the hole on the flywheel, then install the fastening screws without tightening them.
Insert the special tool 1 p/n 1460.301 in the threaded hole on the crankcase to secure the crankshaft against rotation.

- Tighten the screws to a torque of 85 Nm.



SPEED SENSOR - Air gap

Use a thickness gauge to check that the air gap between the speed sensor and the phonic wheel is correct ($0.25 \div 1.10$).
To set the correct air gap, add or remove 0.5 mm shims.



CLEARANCE VOLUME

Position the pistons at the top dead centre.
Measure the distance from the piston crown to the crankcase surface in four diametrically opposite points.
Repeat the operation on all pistons.
The maximum measured value determines the value (A).
According to the measured value, choose the most suitable gasket.
This choice determines the value of the clearance volume (see "Head gasket selection and clearance volume table").



Important

The head gasket must be replaced every time it is disassembled.

Head gasket selection and clearance volume table


A (mm)	Number of holes		Clearance volume (mm)
0,280÷0,380	1		0,340÷0,440
0,381÷0,480	2		0,340÷0,439
0,481÷0,580	3		
0,581÷0,680	4		



166

CYLINDER HEAD

Assemble the cylinder head by referring to the centring pins and without applying a particular pressure.



167



Important

The cylinder head fastening bolts must be replaced at each disassembly.

Tighten the cylinder head screws by strictly following the tightening order specified below.

- Phase 1:** Install the screws without tightening them.
- Phase 2:** Tighten the screws to 10 Nm following the specified order.
- Phase 3:** Tighten the screws to 30 Nm following the specified order.
- Phase 4:** Loosen the screws by 180°.
- Phase 5:** Tighten the screws to 30 Nm following the specified order.
- Phase 6:** Tighten the screws to 50 Nm following the specified order.
- Phase 7:** Tighten by rotating them by 90°, in the specified order.
- Phase 8:** Tighten then tighten again by 90° following the specified order.



168

ROCKER ARMS AND HYDRAULIC TAPPETS

Reassemble the rocker arm and the hydraulic tappet. Make sure they are fully inserted.



169

CAMSHAFT




Important

Position the pistons at the top dead centre.

Generously lubricate the bearings and cams, then assemble the shaft in the cylinder head.

➞ For the dimensional checks, refer to page 89.




170

CAMSHAFT COVER

Spread a thin layer of sealant on the sealing surface, strictly observing the area highlighted in gray, see diagram **A**.

Generously lubricate the bearings.
 Assemble the upper camshaft bearing on the cylinder head, by referring to the centring pins as shown by the arrows.



171



Important

Assemble the upper camshaft bearing with care, since the hydraulic tappets may provoke a collision between valves and pistons, if the latter are at their top dead centre. Before fastening, bring the crankshaft to its BDC.

Do not apply immediately the prescribed torque. Tighten the screws gradually and following the specified order. This procedure will give time to the oil in the tappets to drain away.



Important

In case of breakage or deformation of the camshaft cover, replace the whole cylinder head.


○ Tighten the screws to a torque of 10 Nm, in the sequence indicated.



Important

After correctly tightening all the screws, wait at least 30 minutes before starting the engine at an ambient temperature of 20°C.

Before starting the engine, manually rotate the crankshaft to check that the valves do not collide with the pistons.



172


SEAL RINGS

Camshaft:

Install the seal ring **A** after generously lubricating it. Set the external surface of the ring coplanar with the surface of the centring hub. If the seal ring is worn out, the new oil seal ring must be installed by moving it towards the bottom of the support, so that the seal lip is moved by 1 mm from its previous position (first replacement of the seal ring).

At the second replacement of the seal ring, it must be installed by pushing it fully to the bottom.

The clearance available to move the seal ring from its original position to the bottom position is 2 mm.



173

Crankshaft (flywheel side):

Install the seal ring **C** after generously lubricating it. Set the external surface of the ring aligned with the end of the chamfered opening. Respect the 2 mm indentation value with respect to the crankcase surface.

If the seal ring is worn out, the new oil seal ring must be installed by moving it towards the bottom of the support, so that the seal lip is moved by 1 mm from its previous position (first replacement of the seal ring).

In case the seal ring is replaced again, it must be installed further in by 1 mm with respect to the previous time (second replacement of the seal ring).



174

WATER PUMP

Before reassembling the water pump, apply a layer of silicone sealant 7091 on the crankcase surface (matr. 4776.100).



Important


Never apply an excess of sealant near the rotor to avoid pump overheating.



175

Tighten the screws in a criss-cross pattern.

- Tighten the screws to a torque of 10 Nm.




176

Crankshaft seal rings (timing system side):

Install the seal ring **B** after generously lubricating it. Set the external surface of the ring coplanar with the surface of the centring hub. If the seal ring is worn out, the new oil seal ring must be installed by moving it towards the bottom of the support, so that the seal lip is moved by 1 mm from its previous position (first replacement of the seal ring).

In case the seal ring is replaced again, it must be installed further in by 1 mm with respect to the previous time (second replacement of the seal ring).

Do not move back the seal ring by more than 3 mm, since no mechanical limit stop is provided to ensure the correct operation of the ring.



177

GEAR COVER



Caution - Warning

When assembling the cover, pay particular attention not to damage the oil seal ring **B (fig.181) on the crankshaft.**

Use the special tool **C** p/n 1466.299 to centre the gear cover on the crankshaft.

Tighten the screws of the gear cover, by following the specified order, at a torque of 10 Nm.



Important

The slightest non compliance with the specified tightening order may result in deformations of the oil seal ring **B.**



178

Internal timing belt guard

Assemble the internal timing belt guard and tighten the screws in a criss-cross pattern.


- Tighten the screws to a torque of 10 Nm.



179

TIGHTENING PULLEY

Assemble the tightening pulley without tightening the screws to their final torque.




TOOTHED PULLEY ON CAMSHAFT




Important

Assemble the pulley on the camshaft by making the reference key 2 coincide with its slot 3 in the pulley.



Assemble the gear camshaft, special tool, 1 code ED0014603900, and secure it to the base with the screw 2 to lock the camshaft pulley.

- Tighten the screw to a torque of 80 Nm.



TIMING SYSTEM DRIVE PULLEY


Install the timing system drive pulley on the crankshaft by inserting the key B of the gear in the slot B of the crankshaft.



Secure the crankshaft against rotation using the tool 1, see fig.163.

- Tighten the screw to a torque of 85 Nm.

Remove the flywheel locking tool 1 (fig.163).




184

TIMING BELT SETTING

**Important**


Every time the belt is disassembled it must be replaced even if it has not reached the prescribed time for replacement.

Install the belt by aligning the belt references **A** with the corresponding references on the timing system internal guard **B** and with the references on the camshaft pulley **C** and crankshaft gear **D**.



185

The timing system pulley on the crankshaft is correctly timed when the engraving on the tooth is aligned with the mark on the timing belt internal guard (in plastic) as shown at point **B**.



186

SYNCHRONOUS TIMING BELT ASSEMBLY


**Important**

Remove the belt from its protective wrapping only when ready for fitting.

Install the belt respecting the rotation direction shown by the arrow on the belt itself.

Make the toothed belt references coincide with the ones on the pulleys of the camshaft **1** and crankshaft **3**.

As last, insert the belt in the tightening pulley **4**.



187

SYNCHRONOUS TIMING BELT - Tensioning

Insert the special tool **1** (p/n 1460.325) in the hexagonal hole of the tightening pulley as shown in the figure.

By exerting a force on the tightening pulley, the tool makes it rotate anticlockwise, thus correctly tensioning the timing belt.

Tighten the pulley fastening screw **A** to a torque of 25 Nm without completely tightening it.

Remove the belt tensioning tool **1**



188

- Tighten the screw to a torque of 25 Nm.

Manually rotate the crankshaft some times and repeat the tensioning procedures.



189

EXTERNAL TIMING BELT GUARD

Reassemble the external timing belt guard.

- Tighten the screws to a torque of 10 Nm.



190

ALTERNATOR DRIVE PULLEY

Install the pulley on the crankshaft and fasten it.

- Tighten the screws to a torque of 10 Nm.



191


OIL FILTER

Lubricate the rubber seal with engine oil and screw the oil filter back in.



Important

It is compulsory to screw the oil filter manually.



192

WATER TEMPERATURE SENSOR



Important

Always replace the O-ring.

Manually screw the temperature sensor on the cylinder head.

- Tighten the sensor to a torque of 20 Nm.
- ➡ For the technical specifications see page 43.




193

THERMOSTATIC VALVE



Important

The air bleeding hole F must be turned upwards.



194

COOLANT OUTLET FLANGE



Important

Always replace the O-ring.

- Tighten the screws to a torque of 10 Nm.



195

COOLANT INLET FLANGE

Reassemble the coolant inlet flange on the engine with the duct fitting.

- Tighten the screws to a torque of 10 Nm.



196

GLOW PLUGS




Important

The glow plugs must be tightened using a torque wrench only.

- Tighten the glow plugs to a torque of 10 Nm.

The glow plugs do not have a limit stop in the cylinder head. Therefore, an incorrect tightening may result in serious head damages (see on page 45) and could modify the glow plug protrusion value in the combustion chamber.



197

ELECTRONIC INJECTORS




Important

Always replace the copper gasket 1 before reassembly.

The copper gasket 1 determines the nozzle protrusion from the combustion chamber.

Gasket have different thickness: 0,2 , 0,5+0,5 , 1,5.

The effective dimensional check is to be carried out with the cylinder head disassembled, by measuring the protrusion of the nozzle tip from the cylinder head surface (see page 120).




198

ELECTRONIC INJECTOR FIXING BRACKET



Important

During the reassembly phase, always replace the screw 1 and the washer 2.



199

Insert the injector with its seal.

Assemble the fixing bracket 2.

Partially screw the fastening screw 3 without tightening it.


Repeat the same operation on the second injector.



Important

Reassemble the injector and/or delivery hoses paying attention to the references on the injector and fuel delivery hoses (0 and 1, see photo) marked during disassembly.


If the position of the electronic injectors is changed, the ECU will not detect the expected IMA codes. This will result in poor engine performances.



200

HIGH-PRESSURE PUMP

Position the cam **C** that controls the high-pressure pump on its base radius.



201


Loosen the screw **A** and introduce the tappet in the cylinder head, with the slot **B** aligned with the screw **A**.
When the tappet roller comes in contact with the cam, tighten the screw **A**.

To check if the tappet has been correctly assembled, it must not rotate and allow a limited downstroke.



202

Apply a layer of grease (which acts as a sealant in this case) on the high-pressure pump collar.
Insert the pad with its concave section turned towards the cam.
To determine the pad thickness, see page 91.



203



Important

During the reassembly phase, the pin **1** must be inserted in the positioning slot **2**.

Install the high-pressure pump in the cylinder head.



Important

To avoid damaging the injection system, remove the protection plugs only a moment before connecting to the fittings.



204

Assemble the bracket that fixes the pump to the cylinder head.



Important

Insert the spherical washer respecting the assembly direction and tighten the fastening nut to a torque of 25 Nm.



205

COMMON RAIL

Insert the two fixing columns on the stud bolts.



206



Important

Assemble the Common Rail and screw in the fixing columns without tightening them.



Important

To avoid damaging the injection system, remove the protection plugs only a moment before connecting to the fittings.



207

HIGH-PRESSURE LINES



Important

Assemble the high-pressure lines by manually screwing the fittings, without tightening them.



Important

To avoid damaging the injection system, remove the protection plugs only a moment before connecting to the fittings.



208

ELECTRONIC INJECTORS - Tightening

- Tighten the screw to a torque of 22 Nm.



209

COMMON RAIL FIXING COLUMNS - Tightening

- Tighten the columns to a torque of 25 Nm.



210

INJECTOR FITTINGS - Tightening

Tighten the injectors fittings in sequence.

- Tighten the fittings to a torque of 19 Nm.



211

INJECTION HOSE FITTINGS ON RAIL AND INJECTION PUMP HOSE - Tightening

- Tighten the fittings to a torque of 19 Nm.




212

FUEL HOSES

Assemble the fuel distributor.

- Tighten the screws to a torque of 19 Nm.



213

RAIL

Remove the plug **D** and fit the hose **E** on the Rail discharge fitting.



Important

To avoid damaging the injection system, remove the protection plugs only a moment before connecting to the fittings.



214

Remove the protection plugs **C** from the inlet/outlet fittings of the high-pressure pump.




215

Connect the high-pressure pump return hose by exerting a small pressure on the quick-coupling and check that it is correctly fitted.



216

Connect the supply hose by exerting a small pressure on the quick-coupling and check that it is correctly fitted.



217

Remove the protection plugs **A** from the injector return fittings.



218


INJECTOR RETURN LINE

Manually fit the injector return hose on the fitting by pressing from above and pushing vertically until hearing the lock click. Stop pushing as soon as you have reached the limit stop.



219

Use a plastic hose clamp to secure the return hose to the other supply hoses, to avoid interferences with the acoustic insulation cover.



220

Position the safety filter as shown in the figure.



Caution - Warning

Do not position the filter in a different position to avoid problems to the supply system.



221

STARTER MOTOR

Insert the starter motor in the supporting plate.

- Tighten the bolts to a torque of 45 Nm.




222

ALTERNATOR

Fix the alternator support bracket to the crankcase.

- Tighten the screws to a torque of 25 Nm.



223

Introduce the spacer **B** on the stud bolt that supports the alternator in the lower part, and then fix the alternator to the upper bracket..



224

ALTERNATOR DRIVE BELT

Fit the alternator drive belt on the two pulleys.



225

Tension the belt by pressing on the alternator.

- Tighten the bracket screw to a torque of 45 Nm.
- Tighten the screw in the lower part to a torque of 25 Nm.



226

After manually performing some complete rotations of the crankshaft, use a special tool (**Krikrit**-type) to check the belt tension. When applying a force of 100 Nm on the belt section shown in the figure, the arrow should be 10-15 mm. Using the special tool (**Krikrit**-type) approved by Lombardini, the correct tension value should be 20÷25 kg. Should the tensioning be incorrect, repeat the operation.



227

INLET MANIFOLD



Important

Before reassembling the manifold, always replace the gaskets between cylinder head and manifold.

Reassemble the manifold and the heat protection.

- Tighten the screws to a torque of 25 Nm.



228

AIR FILTER SUPPORT BRACKET

Assemble the air filter support.

- Tighten the screws to a torque of 25 Nm.



229

AIR FILTER DUCT - VENT DUCT

Reassemble the intake duct together with the oil vapours vent duct.



Important


Always replace the clamps when reassembling.



230

AIR FILTER

Fasten the rubber clamp that fixes the air filter to the support.



231

EXHAUST MANIFOLD



Important

Before reassembling the manifold, always replace the copper self-locking nuts and the metal gaskets between the manifold and the cylinder head.

Reassemble the exhaust manifold and install the four nuts.


- Tighten the nuts to a torque of 25 Nm.



232


SERVICE WIRING HARNESS - INSTALLATION

1. Install the accessory wiring harness (see page 38-39 for the wiring diagram).




233

2. Connect the black connector (**MOT**) to the 50 of the starter motor.



234

3. Connect the connector (**ALT**) to the alternator.



235

4. Connect the glow plug supply cables **cn 1** and **cn 2** to the mating glow plugs.


○ Tighten the nuts to a torque of 1 Nm



236

ENGINE WIRING HARNESS - INSTALLATION

1. Install the accessory wiring harness (see page 36-37 for the wiring diagram).




237

2. Connect the oil pressure connector **H** to the oil pressure sensor.

3. Connector **V** must be connected to the mating connector on the engine wiring harness.

4. Connector **G** must be connected to the gearbox speed sensor.




1. Connect the connectors **Q** and **N** to the mating electronic injectors.



Important

Respect the original position: the engine will not work if the connectors are changed.


2. Lock the connectors by fully engaging the yellow securing lever **A**.




3. Connect the connector **R** to the Rail pressure sensor.
4. Lock the connector by fully engaging the yellow securing lever **G**.



5. Connect the connector **T** to the Rail pressure regulator.
6. Lock the connector by fully engaging the yellow securing lever **E**.



7. Connect the connector **P** to the coolant temperature sensor.
8. Fully push downwards the connector until the lock spring is correctly engaged.



9. Connect the connector **L** to the mating cable of the speed sensor.

10. Make sure the lock spring **I** is correctly engaged.



Reassemble the acoustic insulation cover.

[illegible]

TIGHTENING TORQUE TABLES

The tables show the tightening torques for standard screws and the main components.

Tightening torques are provided again, along with method and sequence, in the instructions for assembling components and/or assemblies

Table of tightening torques for standard screws (coarse thread)









Quality/ Dimensions	Resistance class (R)							
								
Diameter	R>400N/mm ²		R>500N/mm ²		R>600N/mm ²	R>800N/mm ²	R>1000N/mm ²	R>1200N/mm ²
	Nm	Nm	Nm	Nm	Nm	Nm	Nm	Nm
M3	0,5	0,7	0,6	0,9	1	1,4	1,9	2,3
M4	1,1	1,5	1,4	1,8	2,2	2,9	4,1	4,9
M5	2,3	3	2,8	3,8	4,5	6	8,5	10
M6	3,8	5	4,7	6,3	7,5	10	14	17
M8	9,4	13	12	16	19	25	35	41
M10	18	25	23	31	37	49	69	83
M12	32	43	40	54	65	86	120	145
M14	51	68	63	84	101	135	190	230
M16	79	105	98	131	158	210	295	355
M18	109	145	135	181	218	290	405	485
M20	154	205	193	256	308	410	580	690
M22	206	275	260	344	413	550	780	930
M24	266	355	333	444	533	710	1000	1200
M27	394	525	500	656	788	1050	1500	1800
M30	544	725	680	906	1088	1450	2000	2400

Table of tightening torques for standard screws (fine thread)



















Quality/ Dimensions	Resistance class (R)							
								
Diameter	R>400N/mm ²		R>500N/mm ²		R>600N/mm ²	R>800N/mm ²	R>1000N/mm ²	R>1200N/mm ²
	Nm	Nm	Nm	Nm	Nm	Nm	Nm	Nm
M 8x1	10	14	13	17	20	27	38	45
M 10x1	21	28	26	35	42	56	79	95
M 10x1,25	20	26	24	33	39	52	73	88
M 12x1,25	36	48	45	59	71	95	135	160
M 12x1,5	38	45	42	56	68	90	125	150
M 14x1,5	56	75	70	94	113	150	210	250
M 16x1,5	84	113	105	141	169	225	315	380
M 18x1,5	122	163	153	203	244	325	460	550
M 18x2	117	157	147	196	235	313	440	530
M 20x1,5	173	230	213	288	345	460	640	770
M 20x2	164	218	204	273	327	436	615	740
M 22x1,5	229	305	287	381	458	610	860	1050
M 24x2	293	390	367	488	585	780	1100	1300
M 27x2	431	575	533	719	863	1150	1600	1950
M 30x2	600	800	750	1000	1200	1600	2250	2700

Table with tightening torques of the main components and use of sealant

Description	Diam. x pitch (mm)	Torque (Nm)	Sealant
Alternator (lower fastening nut)	M 10x1,5	45	
Alternator (upper fastening screw)	M 8	25	
Lower crankcase, sealing surface			Loctite 5450
Speed sensor wiring harness	M 8	20	
Glow plugs	M 10x1	10	
Connecting rod cap	M 7x1	25	
Engine block	M 10x1,5	50	Loctite 5205
Engine block	M 8	25	Loctite 5205
Engine block	M6	10	Loctite 5205
Starter motor/Alternator connecting cable	M6	6	
Glow plug connection nut	M4	1	
Cable on starter motor	M 8	10	
Inlet manifold	M 8	25	
Exhaust manifold	M8	25	
Rocker arm cover	M8	22	
Acoustic insulation cover	M 8	12	
Gear cover	M 6	10	
Decanting device cover	M 6	10	
Cover for glow plug connection cable	M 4	4	
Oil sump	M 6	10	
Fuel distributor	M6	10	
Oil filter	M20x1,5	hand tight	
Coolant inlet flange	M6	10	
Timing belt tightening pulley	M8	25	
Injector fixing bracket	M8	20	
Phase sensor indicator on camshaft	M6	10	
Starter motor on support plate	M10x1,25	40	
Starter motor support plate	M8	25	
Coolant pump	M6	10	
High-pressure pump fixing bracket	M8	20	
Oil pump	M6	10	
Pressure switch	M12x1,5	25	
Exhaust manifold stud bolt	M8	8	Loctite 242
Rail fixing stud bolt	M8	8	
Injection pump stud bolt	M8	8	Loctite 242
Inlet manifold protection	M8	25	
External timing belt guard	M6	6	
Internal timing belt guard	M6	10	
Alternator drive pulley on crankshaft	M6	10	
Timing system drive pulley on crankshaft	M12x1,25	85	
Camshaft timing pulley	M10x1,25	80	
Injection pump tappet	M6	6	Loctite 270
Oil filter union	M20x1,5	15	
Rail fixing	M8	25	
Fuel inlet union on injector body		27	
Speed sensor	M5	6	
Water temperature sensor	M12x1,5	15	
Engine anchoring bracket	M10	50	

<i>Description</i>	<i>Diam. x pitch (mm)</i>	<i>Torque (Nm)</i>	<i>Sealant</i>
Air filter bracket	M8	25	
Alternator support upper bracket	M8	25	
Camshaft bearing	M6	10	Loctite 5205
Camshaft cover support	M6	10	
Oil sump plug	M18	30	
Water thermostat	M6	10	
Cylinder head	M10	50Nm+90°+90°	
High-pressure lines from rail to injectors	M14x1	19	
High-pressure lines from pump to rail	M12x1,5	28	
Oil suction pipe	M6	10	
Oil return line	M6	10	
Pressure relief valve	M12x1,5	15	
Left balance shaft gear fastening screw	M10x1,25	60	
Flywheel	M10x1,25	85	

	<i>Description</i>	<i>Part number</i>
	Camshaft seal ring protection sleeve	ED0014603190
	Protection sleeve for assembling the gear cover oil seal ring	ED0014602960
	Instrument for checking the protrusion of pistons, injectors and glow plugs	ED0014602980
	Gear cover centring tool	ED0014602990
	Dismount / Installation and Tools for Cam Shaft Pulley	ED0014603900
	Cam Shaft phase tool	ED0014603910
	Flywheel locking tool	ED0014603010
	Timing belt tensioning tool	ED0014603250
	Tool for intake and exhaust valve guide seal assembly	ED0014600470
	Diagnostic tool	ED0014603220

This image shows a full page of white paper with horizontal dotted lines. The lines are evenly spaced and run across the width of the page, providing a guide for handwriting practice. There are no margins, text, or other markings on the page.

New diagnosis

Diagnosis
Service
Configuration



New diagnosis
Recent diagnosis
Start OBD
Demo



Lombardini



Lombardini
Diesel



Lombardini
Diesel
LDW 442 CRS



Lombardini
Diesel
LDW 492 DCI
ENGINE ELECTRONICS
--
--
--
12



Lombardini
Diesel
LDW 492 DCI
ENGINE ELECTRONICS
Switch on the control panel

ENTER to continue



Parameters
Statues
Information
Errors
Delete errors
Activations


By using the button , scroll the list till to have display the engine LDW 492 DCI, than press "Enter"

Now we are inside the diagnostic system.


See "Diagnosis Menu"

Diagnostic Menu - Diagnosis


Parameters. It allows displaying all the engine functional parameters. 8 parameters are displayed for each page. To modify the set of parameters to be displayed, select them using the selection arrows. To access the additional information of the selected parameters, press the diamond key.




Statuses It allows displaying the status of the actuators and relays




Information It provides information concerning the programming of the ECU and the codes of the injector delivery class stored in the ECU




Errors It lists the errors present and/or stored in the ECU, provides the description of the error and of its cause and suggests the checks to be carried out.




Delete errors It allows deleting all the errors stored in the ECU




Activation : It permit to load the injectors code on the ECU, and update the programmation file, more update mappings.




Activation Menu : There are different activation test, that are follow descript



In case of important software release or programmation file updating for ECU, Lombardini will release a Technical Bulletin.
In the row where appears "0", it must be wrote the number indicate from Lombardini.




Freeze Frame, this function permit to visualize the parameter recorded about the engine condition, when the error was recorded. This function can be used for understand the origin of the issue, that generate the error.




This function it permit to test if the MIL lamp on the vehicle dashboard it is working properly.
Other functions like : main relè activation, air condition activation etc., can be activated in order to check and verify the main engine components and eventually accessories.

Database menu – Recent diagnosis




Database menu – Start OBD


It allows accessing the diagnosis, if the ECU is recognized



If the ECU is not recognized or in case of problems, the following message will be displayed



Service Menu





LDW 492 DCI AUTOMOTIVE

WORKSHOP MANUAL

cod. __ ED0053029770

La Lombardini si riserva il diritto di modificare in qualunque momento i dati contenuti in questa pubblicazione.
Lombardini se réserve le droit de modifier, à n'importe quel moment, les données reportées dans cette publication.

Data reported in this issue can be modified at any time by Lombardini.

Lombardini behält sich alle Rechte vor, diese Angabe jederzeit zu verändern.

La Lombardini se reserva el derecho de modificar sin previo aviso los datos de esta publicación.

 **LOMBARDINI**
A KOHLER COMPANY
SERVICE

42100 Reggio Emilia – Italia - ITALY
Via Cav. del Lavoro Adelmo Lombardini, 2 - Cas. Post. 1074
Tel. (+39) 0522 3891 - Telex 530003 Motlom I – Telegr.: Lombarmotor
R.E.A. 227083 - Reg. Impr. RE 10875
Cod. fiscale e Partita IVA 01829970357 - CEE Code IT 01829970357



UNI EN ISO 9001 - cert. n° 0446
ISO/TS 16949 - cert. n° 3792

E-MAIL: atlo@lombardini.it
Internet: <http://www.lombardini.it>