

Feilkoder for Lombardini 442 (440) ENGLISH

ERROR CODE LDW 442 DCI

0087 Rail Pressure too low
0088 Rail Pressure too high
0090 Pressure regulator command on common rail DRV2
0115 Engine water temperature sensor diagnosis
0116 Possible problem with water temperature signal
0120 Signal 1 position accelerating pedal
0168 Limitation of performances - gasoil temperature too high
0180 Signal gasoil temperature
0181 Possible problem with signal gasoil temperature
0190 Rail pressure sensor signal
0201 Injector 1 open circuit diagnosis
0204 Injector 2 open circuit diagnosis
0217 Limitation of performances - water temperature too high
0219 Revving
0220 Signal 2 position accelerating pedal
0230 Fuel pump command command
0335 Engine speed signal
0340 Engine phase signal
0380 Glow plug central command
0480 Fan1 relay command command
0500 Vehicle speed sensor signal
0560 Battery voltage signal
0601 Memory error E2PROM central
0604 Ram diagnosis
0605 Rom diagnosis
0606 CPU diagnosis
60B Convertissor A/D
0641 Sensor supply 1 (gasoil pressure sensor on common rail)
0651 Sensor supply 2 (potentiometer 1, pedal Acc ou capteur de phase)
0657 Main relay (diagnosis contact principal circuit)
0685 Main relay command
0697 Sensor supply 3 (potentiometer 2, pedal Acc)
0704 Brake pedal contact signal
0778 Rail pressure regulator command
1301 Classification IMA not done
2135 Concurrence pedal acceleration
2146 Voltage capacitor launch injectors (VBoost)
2226 Atmospheric pressure sensor diagnosis
2296 High pressure control
2299 Concurrence braking pedal contact (braking and acceleration)
0093 String not found